

NanoCourses 2004, Section 3

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Practical Thin Film Technology

The Flatland of Thin Films
Puttin' 'em on and Takin' 'em off

Process Integration
by
Michael Skvarla

Presented by the
CNF Technical Staff
for the education of CNF Users,
Potential Users, and Industrial Sponsors



CNF NanoCourses



Thin Film Technology, page 1



Process Integration

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- A consideration of the sum of ALL processing steps to arrive at the proper parameters for each in order to make a functional (and reliable) device/circuit/system
 - Thermal budgets (stress, diffusion, ...), thermal history
 - Materials interactions and compatibility
 - Selectivity, chemical sensitivity, etch rates
 - Process latitude (reproducibility)
 - Registration (level-to-level)
 - “mystery phenomena” (hand waving and buzz words)
- Steps in a fabrication process are INTERRELATED and can often involve severe conditions
- The final result is due to the combined effects of ALL of the individual steps



CNF NanoCourses



Thin Film Technology, page 2



Integration & Properties, page 1

Process Integration

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Fabrication is the orderly processing of layers of functionality (doping, contacts, insulation, patterns,) in the optimum sequence to produce a “system, circuit, device.”
- Commercial electronic chip: 30+ masks
- Research:
 - 1-3 layers for the simplest (micro-fluidics)
 - Up to 50 for some complex devices (3D integration)



CNF NanoCourses




Thin Film Technology, page 3



Process Integration - BiCMOS

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Thin Film Technology, page 4



Integration & Properties, page 2

Process Integration - - an example

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- A prominent example is the attempt to use a metal for an ion implantation mask (Ions change the electrical properties)
- If the film deposits as columnar grains (NOT continuous film), the ions can pass between the grains and modify the sample



CNF NanoCourses




Thin Film Technology, page 5



Process Integration - - an example

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- A prominent example is the attempt to use a metal for an ion implantation mask (Ions change the electrical properties)
- If the film deposits as columnar grains (NOT continuous film), the ions can pass between the grains and modify the sample
- Expect this  but get this 



CNF NanoCourses



Thin Film Technology, page 6



Integration & Properties, page 3

Process Integration - Approach

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Understand the process
- Characterize the process (individual steps)
***** this can involve extensive experimentation
- Consider the sequence of the steps
- Consider the effects of subsequent processing operations when deciding the parameters for the present step
- Consider engineering tradeoffs for the optimum result
- Be willing to Compromise
- Be willing to modify the process flow (or even redesign it !!)
- Be Creative !



CNF NanoCourses



Thin Film Technology, page 7



NanoCourses 2004, Section 3

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Practical Thin Film Technology

The Flatland of Thin Films
Puttin' 'em on and Takin' 'em off

Properties of Thin Films
by
Michael Skvarla

Presented by the
CNF Technical Staff
for the education of CNF Users,
Potential Users, and Industrial Sponsors



CNF NanoCourses



Thin Film Technology, page 8



Integration & Properties, page 4

Thin Films: Outline

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Introduction
- Terms and Definitions
- Film Attributes
- Growth Mechanism and Kinetics
- Growth Techniques
- A Few Examples



CNF NanoCourses



Thin Film Technology, page 9



CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

1. Introduction

Things to Think About



CNF NanoCourses



Thin Film Technology, page 10



Integration & Properties, page 5

Why Thin Films?

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Thin films play a role in virtually every micro- and nanostructure!

- Conductors : (Metals, metal compounds)
 - Connecting things (transistors) much harder (\$) than making them
 - Typically used for contacts, interconnects, structures
 - Semiconductor devices, MEMS devices, piezoelectric devices
- Insulators: (Electrical isolation, . . .)
 - Dielectrics for MOS structures, capacitors (SiO_x , etc.)
 - Mask applications
- Semiconductors: (transistors, diodes, resistors, capacitors)
 - Epitaxial layers (MBE, OMCVD)
 - Amorphous and polycrystalline layers
 - Solar cells, thin film transistors, electrical contacts



CNF NanoCourses



Thin Film Technology, page 11



“Thin” ??

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Atomic separation in a solid = 0.3 nanometer (10^{-9} m) (few Å)
- -----
- THIN FILMS -- nanometers (monolayers) to microns
 - High Surface/Volume ratio
 - Thin film properties (different from the bulk)
- -----
- Hundreds of atomic layers = micrometers (10^{-6} m)
 - Approaching “bulk” properties



CNF NanoCourses



Thin Film Technology, page 12



Integration & Properties, page 6

“Underlayer” ?? Possible Substrates

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Silicon Wafer -- Most Common -- an incredible material !!
 - “Pure” silicon -- contamination levels in the ppb, ppm range
 - “Perfect” crystal lattice (No defects, irregularities, ...)
 - “Flat” to within micrometers, or nanometers
 - Grown in long cylinders and sliced (like cheese) Czochralski
- Other Semiconductors (III-IV, II-VI, etc.)
 - Gallium Arsenide, Indium Phosphide, GaAlAs, GaAlAsP,
- Others (many): Metals, glass, epoxy, ceramics,
 - Crystalline or Amorphous



CNF NanoCourses



Thin Film Technology, page 13



Growth versus Deposition

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Growth
 - Surrounding Atoms + Surface Atoms ===> FILM
 - Consumes the substrate
 - Oxygen + Silicon Wafer produces Silicon Oxide
- Deposition
 - Surrounding atoms form a product . . . either :
 - 1 in the ambient and deposited onto the surface, or
 - 2 formed directly on the surface (can be “selective” dep)
- Most films grow with their characteristic configuration
- Epitaxy : Film crystal structure “ordered upon” the substrate



CNF NanoCourses



Thin Film Technology, page 14



Integration & Properties, page 7

Thin Film (Material) Functions

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Imaging
- Masking
- Structural
- Optical
- Electrical
- Biological
- Chemical
- Magnetic



CNF NanoCourses



Thin Film Technology, page 15



Integrated Process Flow

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- CAD design
- Lithography (photo ----> ebeam)
- Pattern Transfer
 - Addition (deposition, growth, etc) <-----
 - Subtraction (etching, etc)
 - Modification (ion implantation)
- Analysis
- Go back to CAD -- (Next level of ... 1 .. 3 .. 6 .. 30)



CNF NanoCourses



Thin Film Technology, page 16



Integration & Properties, page 8

2. Attributes



CNF NanoCourses



Thin Film Technology, page 17



Attributes

- Crystal Structure (Atomic planes)
 - Intermixing encouraged (Silicides, . . .)
 - Mixing Discouraged (Diffusion barriers, . . .)
- Grain size
- Composition, defects, inclusions
- Mechanical, optical, electrical, chemical properties
- Adhesion
- Stress



CNF NanoCourses



Thin Film Technology, page 18



Thin Film Thickness!

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Once a thin film is above a critical thickness, it behaves essentially as a bulk material
- Depending on the property, however, this critical thickness ranges from 100 Angstroms (e.g. electronic bandstructure) to several microns (e.g. internal stress)



CNF NanoCourses



Thin Film Technology, page 19



Thin Film Attributes

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- .Thermodynamics:**
 - Free energy, phase diagrams
 - Phase transformations
- Diffusion and Atomic Motion:**
 - Kinetics of phase transformations
 - High diffusivity paths



CNF NanoCourses



Thin Film Technology, page 20



Integration & Properties, page 10

Design Considerations

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Microstructure: Materials are made up of atoms. Many structures may be possible, but you don't always get the one you want! Variables include crystal structure, grain structure, defects, precipitates, voids, compositional variations.

Electrical: Microstructure variations can significantly affect resistivity, mobility, dielectric function.

Atomic Mobility: Diffusivity may be very different from the bulk due to the presence of grain boundaries, voids, etc.

Mechanical: Thin films more likely to be stressed than not. Affects adhesion, general mechanical properties.

Phase Formation: ΔG , ΔH , ΔS , kT may cause formation of unusual phases.



CNF NanoCourses




Thin Film Technology, page 21



Adhesion

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



- Different interfacial layers formed between film and substrate:
 - (1) Abrupt interface
 - (2) Compound interface
 - (3) Diffusion interface
 - (4) Mechanical anchoring at interface



CNF NanoCourses




Thin Film Technology, page 22



Integration & Properties, page 11

Al-Ni Films

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Thin Film Technology, page 23



Stress

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Stress results from forcing atoms to take positions other than their equilibrium positions
- Atomic bonds are broken (or just bent), resulting in intrinsic stress
- Thermal stresses result from unequal expansion/contraction as the temperature changes
- Sample BOW



CNF NanoCourses



Thin Film Technology, page 24




Integration & Properties, page 12

Stress

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- **INTRINSIC** - - Bonds broken or bent
 - Lattice mismatch, contamination
 - Grain growth & phase transformations ==> Volume changes
- **THERMAL** - - Different coefficients of thermal expansion . . .
 - Temperature changes lead to volume changes ---> Stress



CNF NanoCourses




Thin Film Technology, page 25



Stress

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



Tension

Or

Compression

Results in Wafer BOW



CNF NanoCourses



Thin Film Technology, page 26



Integration & Properties, page 13

Crystal Structure

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Single Crystal - - - Long range order (many μm)
 - Every atom finds its place (Atomic planes / Terraces)
-
- Poly-Crystalline - - - Medium range order (10-100 nm)
 - Grains can be LARGE
-
- Amorphous - - - Short range order (a few nm) - -
 - NO long range order



CNF NanoCourses



Thin Film Technology, page 27



CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

3. Growth Mechanism and Kinetics

Vapor-Phase Deposition (Vacuum) <-----



CNF NanoCourses



Thin Film Technology, page 28



Integration & Properties, page 14

Film Production (Vapor phase)

- Source vaporized & transported to the surface
- Particles stick and coalesce into islands
- Islands coalesce into continuous covering
 - Uniform or granulated
- Continuing the process ==> Bulk Materials



CNFS NanoCourses




Thin Film Technology, page 29



Growth Kinetics

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNFS NanoCourses





Thin Film Technology, page 30



Integration & Properties, page 15

Thin Film Morphology

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Thin Film Technology, page 31




Thermodynamics, Kinetics, Nucleation

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Substrate temperature or ion bombardment can dramatically alter the microstructure of the deposited layer
 - Thermodynamics, kinetics, nucleation
- All are involved in what happens, but they also give you a wide range of possibilities

Phase and crystallographic-order transitions in germanium



CNF NanoCourses




Thin Film Technology, page 32



Integration & Properties, page 16

Structure and Microhardness of TiC

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



Structure and microhardness of TiC deposits at various temps (1000x),
from Bunshah and Deshpandey, Physics of Thin Films, vol. 13, Academic Press, San Diego, CA, 1987.



CNF NanoCourses




Thin Film Technology, page 33



Structural Zones in Condensates

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



Structural zones in condensates. [After Thornton (84).]

From Bunshah and Deshpandey, Physics of Thin Films, vol. 13, Academic Press, San Diego, CA, 1987.



CNF NanoCourses



Thin Film Technology, page 34



Integration & Properties, page 17

Grain Boundaries

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Film properties are **STRONGLY** influenced by the characteristics of the grain boundaries
- Diffusion along GB
- Failure Mechanisms (crack initiation, etc)
- Fatigue and Wear



CNF NanoCourses



Thin Film Technology, page 35



Micro-Structure

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



Grain



Bamboo Structure



CNF NanoCourses



Thin Film Technology, page 36



Integration & Properties, page 18

Drain Boundary Diffusion



CNF NanoCourses



Thin Film Technology, page 37



Diffusion Distance

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- At small dimensions, diffusion along high diffusivity paths, such as grain boundaries, can be significant
- Diffusion distance $\approx \sqrt{D_b t}$
- ...where D_b is the grain boundary diffusion coefficient
- Consider Al at 400°C, ($T/T_m = 0.6$), $D_b = 10^{-10} \text{ cm}^2/\text{s}$
 $\sqrt{D_b t} \text{ m,} \gg \text{submicron dimensions !!!}$
- Note -- Bulk diffusion of a few nanometers typical



CNF NanoCourses



Thin Film Technology, page 38



Surface Energy

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- The energy cost to create a surface
 - Binding energy
 - Interatomic potential energy
- Natural systems tend to minimize total energy
 - Volume energy decreases as a crystal (grain) grows
 - Surface energy increases as a crystal (grain) grows
- Liquids ball up to reduce surface energy
- Crystals facet to expose low energy surfaces



CNF NanoCourses



Thin Film Technology, page 39



Bonding

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- van der Waals - dipole interaction
 - Weak → 0.1 eV / atom pair
 - Bonding between planes. e.g. graphitic carbon, mica
- Metallic - electrons delocalize (nondirectionally)
 - Strong → 1-10 eV / atom pair
 - Leads to ductility, high electrical, thermal cond.
- Ionic - charge transfer (nondirectional)
 - Strong → 1-10 eV / atom pair
 - NaCl, ZnS
 - High temperature conductors
- Covalent - Hybridized bonding (directional)
 - Strong → 1-10 eV / atom pair
 - Si, Ge, other semiconductors



CNF NanoCourses




Thin Film Technology, page 40



Integration & Properties, page 20

Surface Energy



CNF NanoCourses



Thin Film Technology, page 41



Surface Energy Effects

- Often thin films are more sensitive to surface effects
- Wetting:
 - Wets - Oil on metal
Water on dirty Si
 - Doesn't wet - Mercury on floor
Water on clean Si
- Faceting - angular dependence of surface energy
 - Specific growth planes during growth
 - Specific etching systems (e.g. KOH)
- Physisorption and Chemisorption
 - Physisorption - atoms stick to surface without a chemical reaction
 - (van der Waals)
 - Chemisorption - additional chemical forces



CNF NanoCourses



Thin Film Technology, page 42



Chemical Reactivity

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Can overcome surface energy tendencies
 - Gold will ball up on Silicon Oxide
 - Titanium will react ==> good adhesion layer
- Other opportunities to overcome surface energy issues:
 - Surface bombardment
 - Reactive deposition
 - Heating



CNF NanoCourses



Thin Film Technology, page 43



Wetting Growth versus Grain Growth

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Wetting Growth vs Grain Growth

Impingement Rate	High
Nucleation Density	High
Surface Energy Ratios	Low
Chemical Reactivity	High
Surface Mobility	Low
Temperature	Low



CNF NanoCourses



Thin Film Technology, page 44



Integration & Properties, page 22

Electrical Properties

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- As dimensions are reduced, resistance of the interconnects increases due to the reduction in cross-sectional area
- $R = \rho L/A = \rho L/Wt$
- However for thin narrow lines, the line dimensions start to become on the order of the electron mean free path and the resistance increases
- For narrow, thin lines the ratio of the conductivity to that of the bulk conductivity is:
 - $\sigma/\sigma_b \propto t$ (where t is the thickness)
- For $W = t$ (square line)
- $R = \rho L/Wt = L/\sigma t^2 = L/\sigma_b t^3$
- OOOPS ! (Large L , Small t , ==> R Immense !!)



CNF NanoCourses




Thin Film Technology, page 45



Electromigration

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- The Kinetic Energy of moving electrons is sufficient to stimulate migration of the atoms in a conducting line
- Leads to electrical shorts and open circuits, device failures



CNF NanoCourses



Thin Film Technology, page 46



Microstructure Effects on Electromigration

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



Poor electromigration resistance



Bamboo structure = good electromigration resistance



CNF NanoCourses



Thin Film Technology, page 47



Properties

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Mechanical Properties:

- Deposited films often have high stresses in them
 - Wafers bend !!
- In as-deposited sputtered Mo films, ~ 1GPa stresses
 - Yield strength of Mo is 0.84 GPa!!!
- Thermal mismatch can cause stresses
- A film of Al is deposited on a RT Si substrate
- Upon heating to 450°C, the stress in this film is ~ 1GPa
 - Again, much greater than the yield stress
- Cracking, void growth

Microstructure Properties:

- Deposition of many materials, e.g. Mo and Ge, results in a columnar grain structure that readily absorbs water and oxygen after deposition
- Does not matter how good the vacuum was during deposition



CNF NanoCourses



Thin Film Technology, page 48



Integration & Properties, page 24

Consequences of Surface Effects

- Islanding
- Pinholes
- Surface Roughness
- Texturing
- Faceting



CNF NanoCourses



Thin Film Technology, page 49



4. Examples



CNF NanoCourses



Thin Film Technology, page 50



Integration & Properties, page 25

Growth/Deposition Techniques

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- | | | |
|------------------|-------------------------------------|---------------|
| • Spin-On | Liquid Suspension | Conformal |
| • PVD | Physical Vapor Dep (Evaporat'n) | Line of Sight |
| • PVD | Sputtering | Conformal |
| • CVD | Chemical Vapor Deposition | Conformal |
| • PE- | Plasma Enhanced- | |
| • LP- | Low Pressure | |
| • MO- | Metal-Organic- | |
| • Epitaxy | | Crystalline |
| • MBE | Molecular Beam Epitaxy | |
| • OMVPE | Organo-Metallic Vapor Phase Epitaxy | |
| • Electroplating | | Selective |



CNF NanoCourses



Thin Film Technology, page 51



a-Si:H Film Growth

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- The next figure is from R.W. Collins et al., Physics of Thin Films, vol. 19, Academic Press, San Diego, CA, 1994.
- The deposition system in this case is designed for plasma-enhanced chemical vapor deposition in the remote He rf plasma configuration
- In this configuration, the SiH₄ is injected into the chamber downstream from a He plasma tube; the substrate is mounted on a heatable platform located downstream from the SiH₄ injector
- The windows on the chamber are oriented for a 70° angle of incidence at the sample surface



CNF NanoCourses




Thin Film Technology, page 52



Integration & Properties, page 26

a-Si:H Film Growth Schematic

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



R.W. Collins et al., Physics of Thin Films, vol. 19, Academic Press, San Diego, CA, 1994



CNMF NanoCourses



Thin Film Technology, page 53



PECVD a-Si:H Deposition

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- The next figure is from R.W. Collins et al., Physics of Thin Films, vol. 19, Academic Press, San Diego, CA, 1994.
- Results for one- and two-layer models are included (see inset)
- Microstructural parameters obtained in the fits using the one-layer model for $t < 12$ s and using the two-layer model for $t \geq 12$ s are shown on page 14



CNMF NanoCourses




Thin Film Technology, page 53



Integration & Properties, page 27

PECVD a-Si:H Deposition Plot

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



R.W. Collins et al., Physics of Thin Films, vol. 19, Academic Press, San Diego, CA, 1994



CNFS NanoCourses



Thin Film Technology, page 55



Summary

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- There are MANY criteria for successful thin film processing
- Many parameters, techniques, materials
- Choices are made based on the desired film properties



CNFS NanoCourses



Thin Film Technology, page 56



Integration & Properties, page 28

NanoCourses 2002, Part 3

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Practical Thin Film Technology

The Flatland of Thin Films
Puttin' 'em on and Takin' 'em off

Evaporation for the Production of Thin Films

by
Michael Skvarla

Presented by the
CNF Technical Staff
for the education of CNF Users,
Potential Users, and Industrial Sponsors



CNF NanoCourses



Thin Film Technology, page 57



Growth/Deposition Techniques

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Spin-On Liquid Suspension Conformal
- PVD Physical Vapor Deposition Line of Sight
- PVD Evaporation
- PVD Sputtering (Scattering) Conformal
- CVD Chemical Vapor Deposition Conformal
- PE- Plasma Enhanced-
- LP- Low Pressure
- MO- Metal-Organic-
- Epitaxy Crystalline
- MBE Molecular Beam Epitaxy
- OMVPE Organo-Metallic Vapor Phase Epitaxy-
- Electroplating



CNF NanoCourses



Thin Film Technology, page 58



Integration & Properties, page 29

Physical Vapor Deposition Techniques

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Physical Vapor Deposition

- Thermal and electron beam evaporation
- Sputtering
- Reactive evaporation / Sputtering
- Co-Evaporation / Sputtering (alloys, compounds)



CNF NanoCourses



Thin Film Technology, page 59



Requirements for Evaporation

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Vacuum
- Source material
 - Reasonable vapor pressure at a reasonable temperature
- Energy input to vaporize material
- Transport to the sample
- Sample holder (variable temp?)
- Preferably a shutter
- Preferably a thickness/rate monitor
- Condense, migrate, react ==> Layer growth
- Post-deposition processing (anneal, etc.)



CNF NanoCourses




Thin Film Technology, page 60



Integration & Properties, page 30

Vacuum System Schematic



Schematic view of a high-vacuum chamber with substrates mounted in a planetary substrate support above the source



CNFS NanoCourses



Thin Film Technology, page 61



How Good Should the Vacuum Be?

- At 10^{-6} Torr, you'll deposit roughly one monolayer per second of crud (e.g. water vapor)
- May or may not be critical for your application



CNFS NanoCourses



Thin Film Technology, page 62



Integration & Properties, page 31

Deposition Rate

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- A reasonable deposition rate requires that the vapor pressure of the material during evaporation should be above 10 mT
- Deposition rate at the sample depends on the geometry
 - Usually a few to many nanometers per second ($\text{\AA}/\text{s}$)



CNF NanoCourses




Thin Film Technology, page 63



Vapor Pressure Curves

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



Equilibrium vapor pressures of several elements and inorganic compounds of interest in electronics related applications



CNF NanoCourses




Thin Film Technology, page 64



Integration & Properties, page 32

Evaporation Sources

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Thin Film Technology, page 65



Element and preparation vapor species	Temp, °C		Support materials		Remarks
	mp	$\mu^2 = 10^{-12}$ Torr	Wire, foil	Crucible	
Aluminum (Al)	660	1100	W	C, Si, TiB ₂ -Si	Wires all materials readily and easily except refractory metals. Alloys with W and molybdenum carbides. Molybdenum carbide particularly.
Antimony (Sb, Sb ₂)	630	100	Mo, Ta, Nb	Oxides, BN, metals, C	Evaporation rates, $\alpha_s \approx 0.5$. Re- spective temperature above mp. Fracture.
Arsenic (As, As ₂)	800	~800	Oxides, C	Evaporation rates, $\alpha_s \approx 0.10$ to 0.15 . Sublimates but requires temperature above 200°C.
Boron (B)	1100	600	W, Mo, Ta, Nb	Metals	Wires refractory metals without difficulty. Reacts with most metals and carbides.
Boron Nitride (B ₂ N, BN)	1300	1000	W, Mo, Ta, Nb	C, refractory oxides, carbides, C, metals	Wires refractory metals. Toxic, particularly B ₂ N dust. Toxic.
Boron (B)	2100	470	W, Mo, Ta, Nb	Oxides, C	Departs from surface supports are difficult and slow because film condenses requires high temperature. Sublimates. Self deposits of C ₆₀ upon reaction system.
Calcium (Ca)	830	2000	Oxides, metals	Departs from surface supports are difficult and slow because film condenses requires high temperature. Sublimates. Self deposits of C ₆₀ upon reaction system.
Calcium Oxide (CaO)	800	800	W	Al ₂ O ₃	Causes arc discharge hindering evaporation. $\alpha_s \approx 1$.
Calcium (Ca), CaO	>2500	>2000	High evaporation rates without difficulty. Reacts with most metals located Cr oxide arc area. Cr oxides carbides are stable to arc discharge.
Chromium (Cr)	>1900	1400	W, Ta	Stable to arc discharge.
Cobalt (Co)	1400	1100	W	Al ₂ O ₃ , BaO	Alloys with W and carbides. Alloys with W and carbides should not weigh more than 20% of thousand to limit dissociation. Small rods should be used.
Copper (Cu)	1084	1000	W, Mo, Ta	Mo, Cr, Al ₂ O ₃	Precisely no interaction with re- fractory materials. Mo partic- ularly for evaporation because it can be machined and conductive heat well.
Gallium (Ga)	30	1100	BaO, Al ₂ O ₃	Alloys with refractory metals. Wires are attracted when 1000°C.
Garnet (Fe ₃ O ₄)	1400	1400	W, Mo, Ta	W, Cr, Al ₂ O ₃	Wires refractory metals but low mobility in W. Form film by electron-beam evaporation.
Gold (Au)	1962	1400	W, Mo	Mo, C	Alloys with W and Mo. Mo carbides form several depositions but overall
Iridium (Ir)	1500	800	W, Mo	Mo, C, BaO, Al ₂ O ₃ , ZrO ₂	Alloys with all refractory metals. Carbs should not weigh more than 20% of W alloyed to limit dissociation. Small rods allow sublimation rates possible. Toxic.
Iron (Fe)	1500	1000	W	Wires refractory metals.
Lead (Pb)	320	700	W, Mo, Ni, Fe	Metals
Manganese (Mn)	650	400	W, Mo, Ta, Nb	Fe, C	Sublimates
Manganese (Mn)	1344	900	W, Mo, Ta	Al ₂ O ₃	Wires refractory metals.

Temperatures and Support Materials Used in the Evaporation of the Elements (Continued)					
Element and protection gas species	Temp., °C		Support materials		Remarks
	mp	$p^{\infty} = 10^{-4}$ Torr	Wire, foil load with Al ₂ O ₃	Refactory oxide	
Molybdenum (Mo)	2600	2000	Small areas by sublimation from Mo foil. Electron-gas evapora- tion preferred.
Nickel (Ni)....	1400	1300	W, W foil load with Al ₂ O ₃	Refactory oxide	Alloys with refractory metals. Small areas by heating. Small rates by sublimation from Mo foil or wire. Electron-gas evaporation preferred.
Palladium (Pd)	1600	1400	W, W foil load with Al ₂ O ₃	Al ₂ O ₃	Alloys with refractory metals. Small sublimation rates possible.
Platinum (Pt)	1770	2100	W	TiO ₂ , SiO ₂	Alloys with refractory metals. Multiwalled W wires offer short evaporation times. Electron- gas evaporation preferred.
Ruthenium (Ru)	1900	2040	W	TiO ₂ , SiO ₂	Small rates by sublimation from Ru foil. Electron-gas evap- oration preferred.
Rhenium (Re, Re ₂) $a = 1.8^{10^3}$	212	240	Mo, Ta, siliconized load 204	Mo, Ta, C, Al ₂ O ₃	Wires or ceramic materials. Wall deposits spoil vacuum system. Ta, $a = 1$.
Silicon (Si)....	1400	1300	BeO, ZrO ₂ , TiO ₂ , C	Alloys with refractory metals are attacked by molten Si and glass are contaminated by SiO. Small rates by sublimation from siliconized Ta rods. Electron-gas evap- oration gives poorest film. Does not melt W. Mo crucible
Silver (Ag)....	961	1000	Mo, Ta	Mo, C	Wires all refractory metals without alloying.
Strontium (Sr)	700	640	W, Mo, Ta	Mo, Ta, C	Wires all refractory metals without alloying.
Tantalum (Ta)	3000	3000	Evaporation by resistance heating of tantalum W wires, or by driv- ing an arc between Ta rods. Electron-gas evaporation pre- ferred.
Tellurium (Te)	450	575	W, Mo, Ta	Mo, Ta, C, Al ₂ O ₃	Wires all refractory metals without alloying. Contaminates vacuum system. $T_{melt} = 0.4$
Tin (Sn)....	232	1300	W, Ta	C, Al ₂ O ₃	Beams with refractory metals. Small sublimation rates from tin foil. Electron-gas evap- oration preferred.
Transition (Cr)	1700	1700	W, Ta	C, Ta ₂ O ₅	Electron-gas evaporation pre- ferred.
Tungsten (W)	3380	3300	Evaporation by resistance heating of tantalum W wires, or by driv- ing an arc between W rods. Elec- tron-gas evaporation preferred.
Vanadium (V)	1900	1800	Mo, W	Mo	Alloys with refractory metals without alloying. Wall deposits spoil vacuum system.
Iron (Fe)....	419	345	W, Ta, Ni	Fe, 44% C, Mo	Wires all refractory metals without alloying. Wall deposits spoil vacuum system.
Boron (B)....	2800	2400	W	Large and irregular alloys with W. Electron-gas evaporation pre- ferred.

Electron Beam Evaporation

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Usually “better” than thermal evaporation
- Less contamination from the source holder
 - Only the desired material is heated
- More suitable for higher melting point materials (T~3000°C)
- Typically better vacuum
- Usually higher deposition rates
- Better control of deposition rates
- More expensive equipment
- Maybe slower turnaround




CNF NanoCourses



Thin Film Technology, page 68



Schematic of an E-Beam Gun



NNIN

CNF NanoCourses




Thin Film Technology, page 69


CORNELL

Thickness Uniformity

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



Deposition Rate
is a function of
Sample Position



NNIN

CNF NanoCourses



Thin Film Technology, page 70

CORNELL

Integration & Properties, page 35

Alloy Evaporation

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- If you want to evaporate an alloy from a single source, the two elements had better have similar vapor pressures
 - (Say no more than 2 orders of magnitude difference at the desired evaporation temperature)
- But don't expect an extremely uniform composition
 - (E.g. possibly zone refining effects)
- Co-evaporation or sputtering is generally preferable for alloys
- For some oxides, you might consider reactive evaporation, but it is rarely used
- Difficult to control?



CNF NanoCourses



Thin Film Technology, page 71



Thickness and Deposition Rate Control

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Straightforward to measure thickness after film is deposited
- There are several thickness profilers (Alpha Step) throughout CNF
- It's a good idea to place an additional substrate (glass slide?) suitably masked to give an independent thickness measurement
- As we discussed in the Thin Film section, deposition rate can have a significant effect on many film properties
- You can crudely determine rate with a timer after the fact
- Much better to use a film thickness monitor



CNF NanoCourses



Thin Film Technology, page 72




Integration & Properties, page 36

Thickness and Deposition Rate Control

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Must be calibrated for each material and geometry
- Typically good for about 20 μm of Al or 3 μm of Au



CNF NanoCourses



Thin Film Technology, page 73




Lift-Off

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



high aspect ratio patterns



CNF NanoCourses



Thin Film Technology, page 74




Lift-Off

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- A valuable research procedure
- Ethan Swint (1999)

Top Metal ----->



Resist Profile ----->

Substrate Metal ----->

Figure 7



CNF NanoCourses



Thin Film Technology, page 75



Summary

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Evaporation is a line-of-sight deposition
- Appropriate to electron beam or photolithography
- A valuable research procedure that can produce films with superior properties with device dimensions from a few nanometers to many millimeters



CNF NanoCourses



Thin Film Technology, page 76



Integration & Properties, page 38

NanoCourses 2004, Part 3

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Practical Thin Film Technology

The Flatland of Thin Films
Puttin' 'em on and Takin' 'em off

Evaporation for the Production of Thin Films by Michael Skvarla

Presented by the
CNF Technical Staff
for the education of CNF Users,
Potential Users, and Industrial Sponsors



CNF NanoCourses



Evaporation, page 1



Growth/Deposition Techniques

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- | | | |
|------------------|--|---------------|
| • Spin-On | Liquid Suspension | Conformal |
| • PVD | Physical Vapor Deposition
Evaporation | Line of Sight |
| • PVD | Sputtering (Scattering) | Conformal |
| • CVD | Chemical Vapor Deposition | Conformal |
| • PE- | Plasma Enhanced- | |
| • LP- | Low Pressure | |
| • MO- | Metal-Organic- | |
| • Epitaxy | | Crystalline |
| • MBE | Molecular Beam Epitaxy | |
| • OMVPE | Organo-Metallic Vapor Phase Epitaxy | |
| • Electroplating | | |



CNF NanoCourses



Evaporation, page 2



Evaporation, page 1

Physical Vapor Deposition Techniques

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Physical Vapor Deposition

- Thermal and electron beam evaporation
- Sputtering
- Reactive evaporation / Sputtering
- Co-Evaporation / Sputtering (alloys, compounds)



CNFS NanoCourses



Evaporation, page 3



Requirements for Evaporation

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Vacuum
- Source material
 - Reasonable vapor pressure at a reasonable temperature
- Energy input to vaporize material
- Transport to the sample
- Sample holder (variable temp?)
- Preferably a shutter
- Preferably a thickness/rate monitor
- Condense, migrate, react ==> Layer growth
- Post-deposition processing (anneal, etc.)



CNFS NanoCourses




Evaporation, page 4



Evaporation, page 2

Vacuum System Schematic

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



Schematic view of a high-vacuum chamber with substrates mounted in a planetary substrate support above the source



CNFS NanoCourses



Evaporation, page 5



How Good Should the Vacuum Be?

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- At 10^{-6} Torr, you'll deposit roughly one monolayer per second of crud (e.g. water vapor)
- May or may not be critical for your application



CNFS NanoCourses



Evaporation, page 6



Evaporation, page 3

Deposition Rate

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- A reasonable deposition rate requires that the vapor pressure of the material during evaporation should be above 10 mT
- Deposition rate at the sample depends on the geometry
 - Usually a few to many nanometers per second ($\text{\AA}/\text{s}$)



CNF NanoCourses




Evaporation, page 7



Vapor Pressure Curves

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



Equilibrium vapor pressures of several elements and inorganic compounds of interest in electronics related applications



CNF NanoCourses



Evaporation, page 8




Evaporation, page 4

Evaporation Sources

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY


RESISTANCE HEATED WIRE




METAL FOIL SOURCE




RESISTANCE HEATED CRUCIBLE



SUBLIMATION SOURCE



RF HEATED CRUCIBLE



CNF NanoCourses



Evaporation, page 9



Temperatures and Support Materials Used in the Evaporation of the Elements


Element and proton-neutron year number	Temp, °C		Support materials		Remarks
	mp	$\mu^2 = 10^{-12}$ Torr	Wire, foil	Crucible	
Aluminum (13)	660	1100	W	Cr, Ru, Ta, Re	Wires all materials readily and without difficulty except aluminum. Alloys with W and molybdenum cannot be melted.
Antimony (51a, 51b)	630	120	W, Ta, Ni	Ta, Re, molybdenum, Cr	Reactive vapor, $\mu = 0.8$. Re- quires temperature above mp. Tin
Argon (Ae)	859	-899	Oxides, Cr	Reactive vapor, $\mu = 0.10^{12} \text{ Torr}$, 0.10^3 N . Sublimates but requires temperature above 800°C.
Boron (B)	1100	800	W, Mo, Ta, Ni	Metal	Wires refractory metals without difficulty. Alloys with most metals except tungsten.
Boron Nitride (B, B2N)	1250	1000	W, Mo, Ta, Ni	Cr, refractory metals, Ta, molybdenum, Cr	Wires refractory metals. Tin, particularly their dust vapors are toxic.
Boron Nitride (B, B2N)	1250	1000	W, Mo, Ta, Ni	Cr, refractory metals, Ta, molybdenum, Cr	Departs from surface sputtered arc discharge and plasma sources.
Calcium (Ca)	840	160	W, Mo, Ta, Pt	Crucible, molybdenum	The conductivity increases with temperature. Sublimates at 1000°C.
Calcium Oxide (CaO, Ca2O)	850	800	W	Al2O3	Caustic arc discharge feedstock.
Chlorine (Cl)	-100	-2000	Current requirement, $\mu < 1$.
Chromium (Cr)	-1900	1400	W, Ta	High evaporation rate without difficulty. Sublimates at 1900°C and is present in Cr oxide products.
Cobalt (Co)	1490	1100	W	Al2O3, ReO3	Cr, molybdenum are reactive with Co.
Copper (Cu)	1084	1800	W, Mo, Ta	Mo, Cr, Al2O3	Alloys with W and molybdenum should not weigh more than 50% of filament so heat transmission, small heat well.
Gallium (Ga)	29	1100	Re, Al2O3	Anodic arc evaporation The modes are arrested above 1000°C.
Garnet (G)	1620	1000	W, Mo, Ta	W, Cr, Al2O3	Wires refractory metals but low mobility in W. Purify glass by electron-beam evaporation process with Cr and W and Mo.
Gold (Au)	1360	1400	W, Mo	Mo, Cr	Mo, Cr, Al2O3, ReO3
Iodine (I)	150	400	W, Mo	Mo, Cr, ReO3, Al2O3, ReO3	Alloys with all refractory metals. Charge should not weigh more than 50% of W filament to limit current. Small heat well. Small filament size possible.
Iron (Fe)	1500	1600	W	Fe, Cr	Tin, Refractories
Lanthanum (La)	3100	700	W, Mo, Ta	Al2O3	Wires refractory metals
Manganese (Mn)	460	400	W, Mo, Ta	Fe, Cr	
Manganese (Mn)	1310	700	W, Mo, Ta	Al2O3	

Evaporation, page 5

Electron Beam Evaporation

- Usually “better” than thermal evaporation
 - Less contamination from the source holder
 - Only the desired material is heated
 - More suitable for higher melting point materials ($T \sim 3000^\circ\text{C}$)
 - Typically better vacuum
 - Usually higher deposition rates
 - Better control of deposition rates
 - More expensive equipment
 - Maybe slower turnaround

Schematic of an E-Beam Gun



NNIN

CNF NanoCourses




Evaporation, page 13


CORNELL

Thickness Uniformity

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



Deposition Rate
is a function of
Sample Position



NNIN

CNF NanoCourses



Evaporation, page 14

CORNELL

Evaporation, page 7

Alloy Evaporation

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- If you want to evaporate an alloy from a single source, the two elements had better have similar vapor pressures
 - (Say no more than 2 orders of magnitude difference at the desired evaporation temperature)
- But don't expect an extremely uniform composition
 - (E.g. possibly zone refining effects)
- Co-evaporation or sputtering is generally preferable for alloys
- For some oxides, you might consider reactive evaporation, but it is rarely used
- Difficult to control?



CNF NanoCourses



Evaporation, page 15



Thickness and Deposition Rate Control

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Straightforward to measure thickness after film is deposited
- There are several thickness profilers (Alpha Step) throughout CNF
- It's a good idea to place an additional substrate (glass slide?) suitably masked to give an independent thickness measurement
- As we discussed in the Thin Film section, deposition rate can have a significant effect on many film properties
- You can crudely determine rate with a timer after the fact
- Much better to use a film thickness monitor



CNF NanoCourses



Evaporation, page 16




Evaporation, page 8

Thickness and Deposition Rate Control

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Must be calibrated for each material and geometry
- Typically good for about 20 μm of Al or 3 μm of Au



CNF NanoCourses



Evaporation, page 17




Lift-Off

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



high aspect ratio patterns



CNF NanoCourses



Evaporation, page 18



Evaporation, page 9

Lift-Off

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- A valuable research procedure
- Ethan Swint (1999)

Top Metal ----->

Resist Profile ----->

Substrate Metal ----->




Figure 7



CNRF NanoCourses



Evaporation, page 19



Summary

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Evaporation is a line-of-sight deposition
- Appropriate to electron beam or photolithography
- A valuable research procedure that can produce films with superior properties with device dimensions from a few nanometers to many millimeters



CNRF NanoCourses



Evaporation, page 20



Evaporation, page 10

NanoCourses 2004, Section 3

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Practical Thin Film Technology

**The Flatland of Thin Films
Puttin' 'em on and Takin' 'em off**

Dry Etching for Pattern Transfer

**by
Meredith Metzler**

Presented by the
CNF Technical Staff
for the education of CNF Users,
Potential Users, and Industrial Sponsors



CNF NanoCourses



Dry Etch, page 1



Outline

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Pattern Transfer
- Plasmas for Materials Processing
- Mechanisms Associated with Plasma Etching
- Plasma Etching Tools and Methods
- Etch Processes
- Artifacts and Effects



CNF NanoCourses



Dry Etch, page 2



Dry Etch, page 1

Pattern Transfer

Also known as Etching



CNFS NanoCourses



Dry Etch, page 3




Pattern Transfer


CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Transfer (etch) pattern defined by resist layer into substrate
- Unprotected areas removed
- “Resist” is typically photoresist but may be any other patterned layer

Original Structure



Etched Structure



CNFS NanoCourses




Dry Etch, page 4



Dry Etch, page 2

General “Subtractive” Processing

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses







Dry Etch, page 5



Dry Etching Examples

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Dry Etch, page 6




Dry Etch, page 3

Why Not Wet Etching?

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Many viable wet etching processes
 - Acids, etc
- Dimensional control
- Commonly used for larger structures or exotic films
- **Not all wet processes are non-directional and not all dry processes are directional, but dry processes generally give more control**



CNF NanoCourses






Dry Etch, page 7



More Dry Etching Examples

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Dry Etch, page 8



Dry Etch, page 4

Dry Pattern Transfer Terms

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- **Dry etching**

- Generic term covering everything using a gas in vacuum to etch, including ion beams

- **Plasma etching**

- Generic term covering dry etching involving plasma excitation
 - Essentially most dry etching but not all

- **Reactive ion etching**

- The specific type of plasma etching we most commonly use
 - More later



CNF NanoCourses



Dry Etch, page 9



Plasmas for Materials Processing

What is a plasma, why do we use it,
and how do we make it?



CNF NanoCourses



Dry Etch, page 10



Dry Etch, page 5

What is a Plasma?

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- A plasma is an ionized gas
 - Ions
 - Electrons
 - Molecular fragments
- Electrically neutral
- Generally electrically excited
 - Various types of EM excitation
- Weakly ionized plasma
 - Only a small fraction excited species
 - Small but important



CNF NanoCourses



Dry Etch, page 11



CNF Processes Using Plasmas

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- DC, RF, and LF Plasmas for Deposition
 - Sputtering
 - Plasma CVD
- DC, RF, and LF Plasmas for Etching
 - DC for Ion Milling and CAIBE
 - Reactive Ion Etching (RIE)
 - Magnetically Enhanced Ion Etching (MIE)
 - Electron Cyclotron Resonance Etching (ECR)
 - Inductively Coupled Plasma Etching (ICP)



CNF NanoCourses



Dry Etch, page 12



Dry Etch, page 6

Role of the Plasma

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Gas by itself is not very reactive
 - $\text{CF}_4 + \text{Si} = \text{zip}$
 - CF_4 plasma + Si = etching
 - Create ions
 - Create electrons
 - Create excited species and radicals
-
- Plasma provides energy to get over the activation barrier or lowers the activation barrier



CNFS NanoCourses



Dry Etch, page 13



Weakly Ionized Plasmas: the Plasma Discharge

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Electrically driven
 - Charge particle collisions (e^-) with neutral gas molecules are important
 - Surface losses at boundaries are important
 - Ionization of neutrals sustains plasma in steady state
 - Electrons are not in thermal equilibrium with ions
 - Weakly ionized and excited
 - Generally <1% ions and radicals
-
- Energy is capacitively or inductively applied



CNFS NanoCourses




Dry Etch, page 14



Plasma Body and Sheaths

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- The body is a perfect conductor
 - Equipotential
- All potential drop is across these sheaths (dark spaces) at each electrode
- Electrons can escape more rapidly at edges than ions
- A potential barrier develops to suppress electron escape
- Ions are accelerated by the sheath to the electrodes
- **Plasma body is more positive than either electrode !!!**



CNF NanoCourses



Dry Etch, page 15



Electrode Area and Sheath Voltages

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Sheath voltages not necessarily the same on both electrodes
- Depends inversely on the 4th power of the electrode area
- Smaller electrode has highest bias and most voltage drop across the sheath
 - Highest energy ion bombardment
- In most RIE processes, sample is on the smaller electrode, getting significant high energy ion bombardment
 - This is typically also the cathode, the driven electrode



CNF NanoCourses




Dry Etch, page 16



Schematic

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNFS NanoCourses



Dry Etch, page 17



What Do These Ions Do to the Material?

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Samples on the electrodes (either electrode) get bombarded by ions
- Inert Ions bombard the surface supplying enough energy to break chemical bonds and/or dislodge atoms
- Reactive Ions bombard the surface and bond with atoms creating **volatile** species
 - Various mechanisms
- Etched atoms, ions and molecules are then pumped out of the chamber
- Ion stimulated chemistry



CNFS NanoCourses



Dry Etch, page 18




Dry Etch, page 9

DC Diode Plasmas

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Introduction of a large DC bias across two plates of unspecified geometry with a low pressure gas between them (.001 - 1 Torr)
- Voltage is greater than the breakdown voltage causing an ionization cascade that leads to a plasma
- Generally used for deposition and inert milling of materials
- Requires conducting electrodes and samples



CNFS NanoCourses




Dry Etch, page 19



RF Diode Plasmas

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- RF power is driven across two plates
- Electrons oscillate at the RF frequency causing ionization
- Electrodes not necessarily conductors
- Constraint: No time average current of the plasma
- But the electrons respond faster than ions
- ==> a DC offset (bias) results so that the positive and negative swing voltages are unequal but the positive and negative swing currents are equal



CNFS NanoCourses




Dry Etch, page 20



RF Plasma Potentials

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Concerned with three potentials
 - (ave) Plasma Potential (V_p)
 - Body of plasma
 - RF input voltage (V_{rf})
 - (ave) DC bias (V_{dc})
- In RF diode Low Pressure RIE
 - Sample on Driven Electrode
 - Ave ion energy = V_{dc}
 - Instantaneous Ion energy at cathode = $V_{rf} - V_p$
 - Instantaneous ion energy at anode = V_p



CNF NanoCourses



Dry Etch, page 21



Mechanisms Associated With Plasma Etching

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Dry Etch, page 22



Dry Etch, page 11

Etching Mechanisms

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Range of mechanisms
 - Completely chemical (spontaneous)
 - Completely physical (ion bombardment)
 - Everything in between
- All important to various extents in different processes
 - Control by choice of configuration and process parameters



CNFS NanoCourses



Dry Etch, page 23



Directionality

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- For the most part, ion bombardment is directional
- Ion stimulated chemical reactions result in directional etching!!
 - One of several mechanisms that promote directionality
- Isotropic and anisotropic are poor word choices



CNFS NanoCourses



Dry Etch, page 24




Dry Etch, page 12

Physical Etching

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Inert Ions bombard the surface
 - Sputter threshold ~ 10 eV
- Ions dislodge atoms from surface
- Surface and sub-surface damage
- Momentum transfer--no chemistry
- Sputtered atoms generally re-deposited elsewhere
- A significant part of many etch processes



CNFS NanoCourses




Dry Etch, page 25



Ion Bombardment Effects

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Adverse effects of excessive physical sputtering
- Caused by
 - Re-deposition of material
 - Angular dependence
 - Sputter yield



CNFS NanoCourses



Dry Etch, page 26



Chemical Etching--Volatile Products

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Removal is enhanced if you can do chemistry and make a volatile reaction product
 - i.e. a reaction product with a high vapor pressure so it will desorb and stay in gas phase
 - Desorb either naturally or under ion bombardment
 - e.g. F atoms reacting to make SiF₄, a gas

GaAs	Not Volatile	Volatile
Aluminum	Not Volatile	Volatile
Copper	Not Volatile	Not Volatile



CNF NanoCourses



Dry Etch, page 27




Ion Stimulated Chemical Reactions

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Gas adsorbs but does not fully react
- Ion bombardment supplies reaction energy

Alternatively:

- Gas reacts fully but doesn't have enough energy to desorb
- Ion bombardment supplies desorption energy



CNF NanoCourses




Dry Etch, page 28



Plasma Passivation and Removal

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Etch reaction may leave something behind
 - Often a carbon or fluorocarbon residue
- May arrest reaction
- Ion bombardment can remove this passivation on **exposed** surfaces
 - Exposed means exposed to ion bombardment
 - Sidewalls are generally NOT exposed
- A mechanism to prevent sidewall etching



CNF NanoCourses




Dry Etch, page 29



Ion Stimulated Removal of Passivation

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Ion bombardment on bottom
 - Passivation removal
 - Etching
- Little ion bombardment on sidewalls
 - No passivation removal
 - Little lateral etching
- DIRECTIONALITY !!



CNF NanoCourses



Dry Etch, page 30



CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Plasma Etching Tools and Configurations



CNFS NanoCourses



Dry Etch, page 31



Dry Etching Tools

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Various tools have been devised to etch materials in plasmas
 - Different physical configurations
 - Different power sources
 - Different gases



CNFS NanoCourses



Dry Etch, page 32




Dry Etch, page 16

Ion Milling

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Plain physical sputtering from an ion beam source
 - Kaufman Ion Source
 - Plasma based
- Typically
 - Ar⁺
 - 500 eV
 - Current 100 mAmp
 - Rate 300-1000 Å/min
- When you don't have a reactive chemical process
 - Magnetic materials
 - Superconductors
 - Hard oxides



CNF NanoCourses



Dry Etch, page 33



Ion Milling at CNF

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Homemade tool
- Wafers up to 3" inch
- Typical rates
 - C 44 Å/min
 - Al 730 Å/min
 - W 380 Å/min
 - Ti 380 Å/min
 - Si 380 Å/min
- Rates fairly uniform across materials
- A purely physical sputtering, momentum transfer technique



CNF NanoCourses




Dry Etch, page 34



Generic Plasma Reactor

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Vacuum system
- Controlled pressure
 - Millitorr range
- Controlled flow of gas
- Power
 - RF, DC, μ wave
- Coupling
 - Capacitive
 - Inductive
- Different configurations of geometry, pressure, power, etc., give you different effects, different techniques



CNF NanoCourses




Dry Etch, page 35



Matching Network (RF)

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- RF Power Supply impedance = 50 Ohms
- Plasma Impedance
 - Complex (non-resistive)
 - Not 50 Ohms
- Matching Network required to facilitate power coupling
 - Unmatched impedance = Large Reflected Power
- Variable LC network
 - Autotune to minimize reflected power



CNF NanoCourses




Dry Etch, page 36



Plasma Etching

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Barrel Reactor
- Wafers immersed in plasma
 - Little ion bombardment
- Generally isotropic
 - Highly “chemical” process
- Plasma Cleaning/ Resist Stripping



CNF NanoCourses




Dry Etch, page 37



(Low Pressure) Reactive Ion Etching (RIE)

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



- Etching with reactive ions generated in an RF plasma
- RF Capacitive Diode Configuration
 - 13.56 Mhz
 - 50-200 Watts
 - 5 - 50 mtorr
 - 2-100 sccm gas flow
 - Rates ~ 100 - 1500 Å/min.
- Various gases depending on material to be etched



CNF NanoCourses



Dry Etch, page 38



Dry Etch, page 19

(Low Pressure) RIE at CNF

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Plasma Therm 72
- Plasma Therm 720
- Homemade Tool
- Both F and Cl chemistries
- Low rate
- High energy bombardment



CNF NanoCourses



Dry Etch, page 39



High Density Plasmas

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Various ways to increase ionization
 - MIE, ECR, ICP, etc
- More electrons =====>
- More ions =====>
- More ion current=====>
 - Lower voltage at same power
 - Lower ion bombardment energy but more ion current
 - More ionization and more reactive radicals
 - Less damage but higher etch rate



CNF NanoCourses



Dry Etch, page 40




Dry Etch, page 20

RF Plasmas in Magnetic Fields: Magnetron

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Magnetic confinement
- $E \times B \implies$ Increased electron path length before wall loss
- More ionization
- More reactive etch species
- Yields higher etch rates



CNFS NanoCourses



Dry Etch, page 41



MIE at NBTC

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- The MIE etches four times faster than our basic RIE tools
- CHF_3
- Predominantly oxide etching
- 3" wafers ONLY !!!!!
- 220 nm/min oxide
- An obsolete technique



CNFS NanoCourses




Dry Etch, page 42



Electron Cyclotron Resonance RIE (ECR)

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



- Excitation tuned to the electron's natural rotational resonance in a magnetic field
 - 2.45 GHz microwaves
 - 875 Gauss
- Power coupled directly into the electron motion
 - More efficient
 - Higher ionization



CNF NanoCourses




Dry Etch, page 43



ECR Etching

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Only a very small region (a flat disk) has the appropriate resonant condition
- All power is adsorbed in small volume
- Ions stream along magnetic field lines
- Additional directionality provided by lower RF bias



CNF NanoCourses



Dry Etch, page 44



ECR at CNF

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Plasma Quest
- 3" and 4" wafers
- Primarily Chlorine gases
- Primarily GaAs and Silicon



CNF NanoCourses




Dry Etch, page 45



Inductively Coupled Plasmas (ICP)

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Power coupled into plasma inductively
- Separate RF substrate bias
- Ionization separated from the acceleration
- High Density Plasma
 - KiloWatts



CNF NanoCourses



Dry Etch, page 46



Dry Etch, page 23

ICP at CNF

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Plasma Therm SLR 770

- 3 systems/2 processes
 - Chlorine etching of Silicon
 - Deep RIE (Bosch™) (two)
- Shallow and deep silicon structures
- 3" and 4" whole Si wafers



CNF NanoCourses



Dry Etch, page 47



Etch Processes and Their Characteristics

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Dry Etch, page 48



Dry Etch, page 24

Lots of Process Parameters

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Type of instrument/plasma
- Gas mixture
- Gas flow rates
- Pressure
- Power
- Temperature
- Fixed recipes will get you close, but.....



CNRF NanoCourses



Dry Etch, page 49



Quantitative Etch Characteristics

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Etch Rate
- Selectivity to mask
 - = Etch rate of mask / Etch rate of material
 - Best if > 1
- Selectivity to substrate
 - = Etch rate of substrate / Etch rate of material
 - Important if you want to “stop” on the substrate
- Uniformity across the wafer



CNRF NanoCourses



Dry Etch, page 50



Dry Etch, page 25

Qualitative Etch Characteristics

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Sidewall and base quality
 - Residue
 - Roughness
- Notching of mask/Undercut
- Directionality/Anisotropy



CNF NanoCourses



Dry Etch, page 51



Commonly Etched Materials

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Many different materials are dry etched using plasmas
- Many Gases
 - CF₄
 - CHF₃
 - SF₆
 - Cl₂
 - BCl₃
 - Oxygen
 - Hydrogen
- Materials commonly etched at CNF
 - Si
 - SiO₂
 - Poly Si
 - Si₃N₄
 - Al
 - W
 - TiW
 - GaAs
 - SiC
 - Resist



CNF NanoCourses



Dry Etch, page 52



Dry Etch, page 26

Common Masks

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

• Plasma	Mask
• CF ₄	Resist, metals
• SF ₆	Oxide, nitride, Al, resist
• Cl ₂	Oxide, nitride, resist (poor)
• O ₂	Inorganic materials



CNF NanoCourses



Dry Etch, page 53



Choices of Gases: Effects on the Etch Process

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Etchant Gases
 - Provide primary etch species
 - Make a volatile compound
- Additive Gases
 - Modify selectivity
 - Modify directionality
 - Promote/remove passivation
 - Increase/reduce etch species concentration
 - Promote plasma stability



CNF NanoCourses



Dry Etch, page 54



Dry Etch, page 27

Etch Gases

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Generally halogen containing gas
 - CF₄, CHF₃, SF₆, Cl₂
- Other etch gases we do not use
 - NF₃, Br₂, HBr, XeF₂



CNFS NanoCourses



Dry Etch, page 55



Halocarbon Naming

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Most halocarbons go by their Dupont trade name
- Freon_{tm} 14, Freon_{tm} 13, Freon_{tm} 23 (Dupont)
 - Halocarbon 14, etc. (other brands)
- Right Digit = Number of F atoms
- Next Digit = One more than the number of H atoms
- 3d digit if used = One less than number of C atoms
- All other atoms are Cl unless otherwise noted
 - Freon 14 = CF₄
 - Freon 23 = CHF₃
 - Freon 12 = CCl₂F₂



CNFS NanoCourses



Dry Etch, page 56



Dry Etch, page 28

Etchant Gases

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

<u>Etchant</u>	<u>Material Etched</u>
• BCl_3	Al_2O_3 , GaAs
• $\text{C}_x\text{H}_y\text{F}_z$	SiO_2 , Si_3N_4
• SF_6	Si, Poly Si
• Cl_2	Si, Poly Si, SiC, Al, GaAs
• O_2	Organic material



CNF NanoCourses



Dry Etch, page 57



Additive Gases

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Oxide Removal BCl_3 , SiCl_4
 - Surface native oxide
- Passivators O_2 , $\text{C}_x\text{H}_y\text{F}_z$
 - Protect sidewalls
- Inert Gases Ar
 - Plasma Stability
 - Ion Bombardment
- Plasma Inhibitors O_2 , BCl_3 , $\text{C}_x\text{H}_y\text{F}_z$, H_2
 - Chemically modify plasma species



CNF NanoCourses



Dry Etch, page 58



Dry Etch, page 29

Inhibiting a CF₄ etch

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Adjusting C,H,O balance by adding small amounts of H₂ and O₂
- Add H
 - Reduces free F
 - Polymer formation increases
- Add O
 - Ties up CF₃ radicals
 - Reduces free F
 - Polymer formation decreases
- Important for control of passivations and directionality



CNF NanoCourses



Dry Etch, page 59



CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Typical RIE Processes at CNF



CNF NanoCourses



Dry Etch, page 60



Dry Etch, page 30

Resist Stripping with the PT 72

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Low pressure RIE in Oxygen
- O₂ plasmas break down organic materials
 - Typical pressure
 - Typical flow
- Resist etch rates are about 0.1 μm/min
- The addition of a small percentage of CF₄ to the plasma for the first two minutes of the etch can help remove a burned polymer layer produced in fluorine based plasmas



CNRF NanoCourses



Dry Etch, page 61



Resist Stripping with the Branson

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- P2000 Plasma Asher
 - Plasma etching tool
- Oxygen
- 0.1 μm/min
- 1000 Watts
- Resist strip and descum
- Not after halogen plasma



CNRF NanoCourses



Dry Etch, page 62



SiO₂ Etch

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- CF₄ and CHF₃ plasmas are best suited for oxide etching
- The addition of H₂ to CF₄ plasmas reduces the number of fluorine radicals in the chamber
 - Increases passivation
 - Increases selectivity to silicon
- Etch rates in the MIE are greater than 200 nm/min
- Etch rates in our RIE systems vary from 30 to 60 nm/min



CNFS NanoCourses




Dry Etch, page 63



Cl₂ Etching Process for Si - Anisotropic

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Cl₂ etches silicon
- Cl₂ doesn't etch silicon dioxide
 - Oxide makes a good mask
- Must remove surface oxide
- Multistep process
 - Step 1: Dehydrogenate w/ H₂ at low power
 - Step 2: Native oxide etch with BCl₃
 - Step 3: Etch with Cl₂ using BCl₃, H₂ additives
- Rates as high as 0.35 μm/min



CNFS NanoCourses



Dry Etch, page 64




Dry Etch, page 32

Isotropic Si Etching w/SF₆

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- SF₆ with very little O₂ or Ar for stability

- ICP 770
 - 0.2 μm/min
- PT 72
 - 0.1 μm/min



MacDonald Group



CNF NanoCourses




Dry Etch, page 65



Bosch Etching - Deep RIE

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Isotropic fluorine etch driven into anisotropy by a cyclic process deposition/etch process
- Etch rates from 1.6 to 2 μm/min
- Vertical
- Shaped profiles possible



MacDonald Group



CNF NanoCourses



Dry Etch, page 66




Dry Etch, page 33

Bosch Process, Continued

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Aspect ratios as high as 40:1 can be achieved with some process development
- 50 μm diameter via holes through 3" wafers can be etched in nearly 4 hrs
- Silicon only



CNRF NanoCourses



Dry Etch, page 67



Al Reactive Ion Etching

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- PT 720
- Cl₂ etch process
- BCl₃ for oxide removal
- H₂ assists in sidewall passivation for directionality
- Resist mask typically used
- Significant lateral etching when you hit the silicon substrate



CNRF NanoCourses



Dry Etch, page 68




Dry Etch, page 34

Artifacts and Effects



Pressure/Energy Considerations

- General rules to follow
 - Increasing Pressure:
 - Reduces sputtering, and promotes isotropy
 - Decreasing Power:
 - Reduces sputtering, increases Isotropy
 - Decreasing Pressure:
 - Also reduces etch rate



Temperature Control

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Lots of power into wafer
- “Wafer temperature” is important
 - Chemical reaction
- Wafer temperature is generally unknown and difficult to control or measure
- Extremely poor heat conductivity TO THE WAFER in vacuum
- Small problem with low powers (100 W)
- BIG PROBLEM with high powers (1000 W)



CNF NanoCourses



Dry Etch, page 71




Heat Transfer in Vacuum

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- What happens to energy put into wafer?
- Poor heat transfer out of wafer in vacuum
- Few point contacts
- Applies to all vacuum processes
- Easy to get 100°C temperature difference even if you are actively cooling the electrode ! ! !
- Easily melt resist

Exaggerated view of wafer-electrode interface



CNF NanoCourses



Dry Etch, page 72




Dry Etch, page 36

Backside He Heat Transfer

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Bleed small amount of inert gas (He) into cavity behind wafer ($1\text{-}10$ torr).
- Molecular heat transfer medium
 - (mfp > wafer gap)
- Many, many bounces each carrying small amount of energy
- Wafer clamp
- Used on all high power etch and deposition systems



CNF NanoCourses



Dry Etch, page 73



“Loading” -- Various Kinds

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Process variation due to variations in amount of material
 - Chemical supply effects
 - Many wafers may not etch the same as one wafer
 - Inside of the wafer may not etch the same as the outside
 - Small features may not etch the same rate as big features
 - Etch rate not constant as you go VERY deep
 - Dense patterns not same as sparse patterns
-
- Diffusion of reactants and reaction products
 - Consumption of reactants
 - A classical chemical engineering problem



CNF NanoCourses




Dry Etch, page 74



Loading Examples

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNFS NanoCourses




Dry Etch, page 75



“Grass”

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- “Black Silicon”
- Wafer looks black to the eye
- Very rough “spikes” in etched area in SEM picture
- Micromasking by sputtered, non-etching contamination
 - Mask
 - Electrode or chamber
- Either a process problem or a system malfunction
 - Excessive ion bombardment of non-etchable stuff
- Ugly -- VERY BAD



CNFS NanoCourses




Dry Etch, page 76




Grass - Micromasking

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



Rather than



You get



because



Micromask may come from sample or from chamber walls



CNRF NanoCourses




Dry Etch, page 77



Residue

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Polymer residue from etch gases
 - Polymeric residue from resists
 - Redeposited etch materials
 - Mixture of all
-
- Very difficult to remove in standard solvents
 - Some very aggressive solvent mixtures available



CNRF NanoCourses




Dry Etch, page 78



Undercut

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Excessive lateral etching
- Loss of dimensional control



CNRF NanoCourses





Dry Etch, page 79



Base Notching / Sidewall Taper / Faceting

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- A signature of excessive ion bombardment
 - Too much bias voltage
 - Not enough “chemistry”



CNRF NanoCourses



Dry Etch, page 80




Dry Etch, page 40

Resist Wear Out

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Edges
- Plane



CNF NanoCourses



Dry Etch, page 81



Summary

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- “Plasma Etching” (broad sense) is one of the most heavily used techniques in CNF
- At least 11 tools available
- Many variables and parameters effect results
- Processes transfer poorly from one tool to the next
- What is best for someone else may not be best for you
- There is SCIENCE involved
 - Try to understand the recipes and the results



CNF NanoCourses



Dry Etch, page 82



Dry Etch, page 41

NanoCourses 2004, Part 3

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Practical Thin Film Technology

**The Flatland of Thin Films
Puttin' 'em on and Takin' 'em off**

Sputtering

by

Jerry Drumheller

Presented by the
CNF Technical Staff
for the education of CNF Users,
Potential Users, and Industrial Sponsors



CNF NanoCourses



Sputtering, page 1



CVC Sputtering System at CNF

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Sputtering, page 2



Sputtering, page 1

Thin Film Deposition by Sputtering

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

What is Sputtering?

- Ejection of atoms from a solid surface by energetic atomic particles
- An ion impact (fast atom) phenomena
- Primarily a momentum transfer process

It is Universal to all Ion Impacts:

- Used to remove material in a controlled fashion
 - Ion milling
 - Depth profiling
- Undesirable effect in ion implantation
- Usually used to transport material from one surface to another
- Thin film deposition



CNFS NanoCourses



Sputtering, page 3



Ion Impact Phenomena

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Sputtering is a momentum transfer process
- Energy is transferred to many surface/bulk atoms
 - (Not simple 1 on 1 billiard ball collisions)
- Atoms ejected with energies of < 10 eV
- Mixing
- Threshold for sputtering -- tens of eV
- Clusters
- Yield (> 0.5 to 5 atoms per ion)
 - Function of angle, energy, mass of ions and target atoms



CNFS NanoCourses




Sputtering, page 4



Sputtering, page 2

Ion Impact

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNFS NanoCourses



Sputtering, page 5



Sputter Deposition

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- **Caution:**

- More often than not, the term sputtering is used to refer to sputter deposition!

- **Ion impact is used to transfer material from:**

- Source (target) (the pure material), to Substrate (sample)



CNFS NanoCourses



Sputtering, page 6




Sputtering, page 3

Target & Sample

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Cathode (Target)



CNFS NanoCourses



Sputtering, page 7



Why?

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Non-Thermal;
 - Ability to do other materials
- Extended Source;
 - Step coverage, Large areas
- Alloys;
 - What you have is what you get
- Compounds;
 - Reactive sputtering



CNFS NanoCourses



Sputtering, page 8



Sputtering, page 4

Where is Sputtering (Sputter Deposition) Used?

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Architectural glass
- Barrier layers
- Car bumpers
- Decorative Coatings
- Electronics
- Optics
- Plastics
- Protective Coatings
- Wear Coatings



CNFS NanoCourses



Sputtering, page 9



Ways To Do Sputter Deposition

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Ions from an Ion Beam (directed at Target):
 - More versatile, research
- Ions from a Plasma:
 - More common and practical



CNFS NanoCourses



Sputtering, page 10



Sputtering, page 5

Glow Discharge Sputtering

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

First of all: What is a Plasma?

- An ionized gas
 - In our case, it is a low pressure gas with both positive and negative charges as well as energetic neutrals
- Plasmas generated by DC and/or RF glow discharges are widely used in thin film processing as a source of ions
- RF, Low Frequency (audio range), and Microwave
- Usually parallel plate capacitor, but other configurations are used, such as cylindrical
- Vacuum, low pressure controlled atmosphere used



CNFS NanoCourses




Sputtering, page 11



Glow Discharge Sputtering System

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNFS NanoCourses



Sputtering, page 12



Sputtering, page 6

DC Glow Discharge

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- High voltage DC across a low pressure gas
- Ionization
- Electrons accelerated
- Cause more ionization, etc
- These plasma characteristics also apply to Plasma Etching



CNRF NanoCourses




Sputtering, page 13



Abnormal Glow

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNRF NanoCourses



Sputtering, page 14




DC Diode

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Anode = Chamber Walls

Cathode = Target



(Not Usually)



CNFS NanoCourses



Sputtering, page 15



Operating Characteristics:

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Pressure: 20 - 50 mtorr
- V: 2000 - 3000 volts
- I: Hundreds of millamps (up to 1 amp)
- Power: Kilowatts
- A HOT process -- lots of sample bombardment
- Sample and Target must be conductors
- Not widely used anymore
- AC DISCHARGE
- As we go to low frequency AC, ions and electrons follow the field and it acts like a varying DC discharge



CNFS NanoCourses



Sputtering, page 16



However:

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- At > 50 kHz ions can't keep up
- Electrons gain energy from the RF field and cause more ionization
- Plasma is easier to maintain
- Less bombardment of substrates
- Electrodes do not have to be conductors



CNFS NanoCourses



Sputtering, page 17



RF Glow Discharge

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Typically 13.56 MHz
- Reasonably common
- Average field is similar to DC discharge



CNFS NanoCourses



Sputtering, page 18




Sputtering, page 9

RF Plasma

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- What kind of load is a plasma?
- Partially Resistive:
conduction through sheaths
- Partially Capacitive



CNFS NanoCourses




Sputtering, page 19



How?

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



How do we deliver power to such a load?

Matching Network.



CNFS NanoCourses



Sputtering, page 20



Sputtering, page 10

RF Matching Network

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- A device set up as a variable series/parallel load used to match the impedance of the generator to the impedance of the load
- Maximize Transmitted (applied) power
- Minimize Reflected power
- Keep the power supply happy
- Generator has $Z_{out} = 50\Omega$ resistive
- Plasma has $Z_{out} \neq 50\Omega$ resistive and capacitive
- We must make the generator see net 50 ohms impedance



CNF NanoCourses




Sputtering, page 21



RF Generator

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



Manually tune for minimum reflected power

or

Auto tune, using feedback and detected phase shifts



CNF NanoCourses



Sputtering, page 22



Sputtering, page 11

CVC Sputter Coater, Open For Loading

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses




Sputtering, page 23



All That Was Plasmas in General

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- How do we use plasmas to do glow discharge sputtering?
- DC Diode or RF Diode



CNF NanoCourses



Sputtering, page 24



Sputtering, page 12

Magnetron Glow Discharge

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Third type of plasma
- We need faster deposition (more throughput) So,
- We want DENSER plasma, more ion bombardment
 - We can't arbitrarily increase pressure
 - We need to get more ionization per electron
- Confine the electrons (Plasma) magnetically
- Result:
 - More ionization; electrons spiral, longer path
 - Lower impedance plasma, more current, less voltage
 - Electrons are trapped, away from the anode surfaces
- Usually very non-uniform sputtering due to magnetic field
- We have to find ways to correct or compensate for this



CNF NanoCourses



Sputtering, page 25



Planar Target Assembly

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Usually seals in to become part of vacuum wall
- Water cooled backing plate
- Non-uniform deposition with magnetron--substrate motion and shields used to improve uniformity



CNF NanoCourses




Sputtering, page 26



Disk Cathode Bar Magnet Arrangements

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



Disk cathode bar magnet arrangements; (a) radial magnets (b) central rod magnet



CNF NanoCourses




Sputtering, page 27



Planar Magnetron Sputtering

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Sputtering, page 28



Sputtering, page 14

Used Target



CNFS NanoCourses



Sputtering, page 29



Shields to Correct for Coating Non-Uniformity

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Shield used to give uniform
coating thickness

- Located as close as possible to substrates

Sputter Target

“Racetrack” = Ring of greatest sputter removal rate



CNFS NanoCourses



Sputtering, page 30



Sputtering, page 15

Sputter Shield

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNRF NanoCourses




Sputtering, page 31



Planar Target Assembly

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNRF NanoCourses



Sputtering, page 32



Sputtering, page 16

Three Targets & Ion Beam

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Sputtering, page 33



Sputtering Targets

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Target Bonding:
 - Epoxy bonding
 - Metallic Bonding
 - Targets:
 - 99 % to 99.9999 % Purity
 - Vacuum cast
 - Pressed powder
- Our system has 8 inch diameter, 1/4 inch thick disks
- Cost:
 - Backing Plate -- \$3000
 - Bonding -- \$ 400
 - Target -- \$500 - \$2500 (These are not precious metals)
 - \$4000 - \$6000 for each new material



CNF NanoCourses




Sputtering, page 34



Sputtering, page 17

A Typical Sputtering System

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNFS NanoCourses



Sputtering, page 35



Rotating Substrate Carrier

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNFS NanoCourses



Sputtering, page 36



Sputtering, page 18

Sputter Deposition Processing

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Some Terms:

- **Presputtering:** Plasma is used to sputter clean the target surface before coating, by running the plasma with the shutter closed
When is it clean?? Watch the voltage!
- **Backsputtering:** Use applied bias to generate a plasma between the sample and other shields, thus attracting ions to the samples to “sputter clean” them before deposition
(Can cause redistribution of dirt)
- **Ion Beam Cleaning:** Using a dedicated internal ion beam source for in-situ substrate cleaning
- **Bias Sputtering:** Sputtering with negative substrate bias applied
Can modify film structure and composition



CNFS NanoCourses



Sputtering, page 37



Substrate Bias

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- We can apply a negative voltage to the substrate
 - RF or DC
 - Direct or capacitively coupled
- Positive bias will increase the anode sheath voltage
 - Usually avoided



CNFS NanoCourses



Sputtering, page 38



Sputtering, page 19

Bias Sputtering

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Use negative substrate bias during sputtering
 - Enhanced ion bombardment of samples
- Why??
- Direct energy to substrate to:
 - Modify film growth
 - Change crystal structure, grain structure
 - Sputter off loose impurities, improve film properties
 - Resputter to alter composition, step coverage, etc
 - Modify stress
- Also:
 - Heats substrates
 - Damage
 - Stress



CNRF NanoCourses




Sputtering, page 39



No Substrate Bias

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNRF NanoCourses




Sputtering, page 40



Sputtering, page 20

Positive Bias on the Substrates

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses




Sputtering, page 41



Ion Beam for Substrate Cleaning or Film Modification

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Sputter off the top atom layers of the substrates
- Can harden films or change composition



CNF NanoCourses



Sputtering, page 42



Process Sequence

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Typical Deposition Sequence:

- ❖ Vent Chamber
- ❖ Load substrates, and evacuate to required base pressure
- ❖ Set up Argon flow and pressure
- ❖ Back sputter, or ion beam clean substrates
- ❖ Turn on sputter power supply
- ❖ Pre-sputter to clean target
- ❖ Open shutter
- ❖ Deposit on sample for given time
- ❖ Shut off power or close shutter
- ❖ Vent, remove substrates
- ❖ Evacuate chamber



CNRF NanoCourses



Sputtering, page 43



Reactive Sputtering

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- What if we want to make an oxide or nitride?
- Sputtering a compound target may not give you what you want!
- We can sputter in reactive gas
- e.g.
 - $Ti + (Ar, N_2)$ -----> TiN_x
 - $Si + (Ar, O_2)$ -----> SiO_x
 - $SiO_2 + (Ar, O_2)$ -----> SiO_x
- Problem: Compound control
- Question: Is the compound synthesized at the target or at the substrate?
- Answer: Both or either! (Depends primarily on the gas partial pressures used. This determines sputter rate vs. reaction rate.)



CNRF NanoCourses




Sputtering, page 44



Sputtering, page 22

Reactive Sputtering

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNRF NanoCourses




Sputtering, page 45



Case 1: (Slow Deposition)

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNRF NanoCourses




Sputtering, page 46



Sputtering, page 23

Case 2: (Faster Deposition)


CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Sputtering, page 47



Sputtering, page 24

Sputtering of Alloys and Compounds

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- At steady state, material released from the target surface has to equal the composition of the target
- For many alloys and compounds, the deposited film will also equal the target composition
- Qualifications:
 - No diffusion in target
 - Anisotropic
- This makes it relatively easy to sputter alloys and get the desired composition
- (Unlike evaporation)



CNFS NanoCourses




Sputtering, page 49



Different Yields and the Altered Layer

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNFS NanoCourses



Sputtering, page 50



Heat Load

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Only 1% of applied power goes into sputtered atoms
- 75% goes into target heating
- 24% goes into substrate heating, electrons, ions, neutrals
- Substrates are basically thermally isolated in most cases
- Rate of heat rise; can be significant, especially in longer depositions



CNFS NanoCourses



Sputtering, page 51




Stress

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Thin films can be highly stressed (All modes of deposition)
- Film may want to contract or expand with respect to the substrate

Compressive

Film wants to expand.



Tensile

Film wants to contract



Film will tend to crack or haze.



CNFS NanoCourses



Sputtering, page 51



Effects of Stress

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- "Soft" materials will deform to accommodate stress (hillocks)
- NOT an insignificant effect
- Can bend (bow) a 3" wafer 50 μm in the middle
- Can cause peeling, cracking, etc
- Defects, also electrical



CNRF NanoCourses



Sputtering, page 53



Sources of Stress

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Two primary sources:
 - Thermal
 - α Thermal expansion
 - α substrate \neq α film
 - $T_{dep} \neq T_{room}$
 - Intrinsic:
 - Due to non-equilibrium structure
 - Not grown at equilibrium
 - Bonds are not relaxed, etc
 - *Greatest source of stress in sputtered films*
- Evaporated Films:
 - Stress not very significant, usually
 - Most are slightly tensile
- CVD: Some thermal stress
- Sputtering:
 - Lots of stress, tensile or compressive, mostly intrinsic



CNRF NanoCourses




Sputtering, page 54



Sputtering, page 27

How to Measure Stress



CNFS NanoCourses



Sputtering, page 55



Controlling Stress

- Energetic particle bombardment induces....
- Compressive stress
- Pressure effect:
 - Bombardment by fast neutrals
 - Atomic peening
 - Non-equilibrium atomic spacing
- As p increases, less neutral bombardment, more tensile film
- As p decreases, more neutral bombardment, more compressive film
- Can be very pressure sensitive, ± 1 mtorr



CNFS NanoCourses




Sputtering, page 56



Sputtering, page 28

Pressure Graph

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Sputtering, page 57



Gas Incorporation

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Films may have up to 10% incorporated gas
- Substrate bias:
 - Gas content increases with increasing bias
 - More bombardment
 - Implantation of ions
- Target - voltage / power:
 - Gas content increases with target voltage, implantation of neutrals
- Substrate temperature:
 - Gas content decreases with increasing substrate temperature
- Pressure:
 - Gas content increases with decreasing pressure
 - (Lower pressure, more ion / neutral bombardment)



CNF NanoCourses



Sputtering, page 58



Step Coverage

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Unbroken, uniform coverage over non planar substrates
- In sputtering we have:
 - Large area source
 - Randomized arrival directions (high P)
- Step coverage is (can be) better in sputtering than in evaporation
- This can be desirable, or undesirable, depending on what you want to do



CNFS NanoCourses




Sputtering, page 59



Step Coverage Diagram

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNFS NanoCourses



Sputtering, page 60



Sputtering, page 30

Grain Structure

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Film growth (particularly in sputtering) is a non-equilibrium process
- Grain size / type is determined by mobility of nucleating atoms on surface
- Mobility is a function of:
 - Substrate temperature
 - Diffusion (related to melting temperature, roughly)
 - Extra energy inserted by ion / neutral bombardment
 - Substrate - adsorbate bonding



CNRF NanoCourses




Sputtering, page 61



The 'Famous' Diagram (After Thornton)

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNRF NanoCourses



Sputtering, page 62



Sputtering, page 31

Some Characteristics of Sputtered Deposition

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- No spitting from source as in evaporation (can have arcing)
- Process is similar for most materials
- Can sputter high melting point materials easily
- Large area targets:
 - Easier to get uniformity over large areas, high volume production
- Can sputter alloys / compounds without undue fractionation
- In situ cleaning with ions
- Step coverage
- May or may not have less heat load
- Differences in grain structure, adhesion, impurities
- Lift off usually difficult to impossible due to:
 - Heating resist, sidewall coverage



CNF NanoCourses



Sputtering, page 63



Evaporation

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Sputtering is much more widely used in production than evaporation
- Evaporation is sometimes easier and preferable in a lab

However...

- Different, but not necessarily better



CNF NanoCourses



Sputtering, page 64



Sputtering, page 32

Commonly Sputtered Materials

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Al and Al alloys for IC metallizations:
 - Al + 4% Cu
 - Al + 1% Si
 - Al + 4% Cu + 1% Si
- TiW Barrier layer 10% Ti (atomic) 90% tungsten
- We have:
 - Al, Al alloys, Co, Cr, Cu, MgO, MoSi₂, Nb, Si, SiO₂, Ta, Ti, TiW, W
- Conductors:
 - Magnetic materials
 - Compact disks
 - Optical materials



CNF NanoCourses



Sputtering, page 65



CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Summary



CNF NanoCourses



Sputtering, page 66



Sputtering, page 33

NanoCourses 2004, Section 3

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Practical Thin Film Technology

**The Flatland of Thin Films
Puttin' 'em on and Takin' 'em off**

Chemical Mechanical Polishing (CMP)

by
Dan Woodie

Presented by the
CNF Technical Staff
for the education of CNF Users,
Potential Users, and Industrial Sponsors



CNF NanoCourses



CMP, page 1



Chemical Mechanical Polishing

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Developed by IBM in the late '80s
- Originally called Chemical Mechanical Planarization (CMP)
- Utilized to planarize (flatten) step heights in IC wafers
- Currently, CMP is a high growth area in the IC industry utilized for all advanced (0.35 μm and below) devices
- Innovative idea when first applied by IBM
 - Spend billions on equipment to keep wafers clean and particle free
 - Make sure all processing equipment does not touch 'pristine' surface of wafer
 - Put wafer in polishing tool and rub abrasive across the surface



CNF NanoCourses



CMP, page 2




CMP, page 1

Why Planarize?

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Step heights are created when patterning wafers with thin films
- Can affect further processing steps



CNF NanoCourses




CMP, page 3



How Else to Planarize?

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Several other techniques have been developed
 - Borophosphosilicate glass (BPSG) Reflow
 - Spin on Glass (SOG)
 - Resist Etchback



CNF NanoCourses



CMP, page 4




CMP, page 2

Problems with Planarizing

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Other planarization techniques only partially remove step heights
- Local planarization instead of global planarization
- Limited ICs to 3-4 wiring levels



CNF NanoCourses




CMP, page 5



CMP – A New Approach

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Deposit film thicker than needed
- Polish film down until step heights are removed
- Process achieves global planarization... for the most part
- Allows for up to 9+ wiring levels in ICs



CNF NanoCourses



CMP, page 6



CMP, page 3

Strasbaugh 6EC – Lab Polisher

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Polishing table covered with polishing pad / slurry
- Carrier holds wafer against pad while turning
- Conditioning Arm – maintains removal rate
- Can process 3, 4, & 6 inch whole wafers only



CNF NanoCourses







CMP, page 7



Damascene CMP - CMP's Other Trick

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Connects wiring levels in ICs
- Can be used for other materials as well



CNF NanoCourses







CMP, page 8



Dual Damascene- An Even Fancier Trick

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Developed in the effort to make things cheaper / faster
- Utilized for all Cu wiring in advanced devices (i.e. Pentium 4, PowerPC)



CNF NanoCourses



CMP, page 9



CMP Consumables

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Polishing Pads
 - Material designed for the purpose of the polishing
 - Hard for planarization / damascene polishing
 - Soft for reducing surface roughness
 - Needs to be compatible with the slurry being used
 - Hard pads need conditioning to maintain etch rates
- Slurries
 - Chemical / Mechanical action determined by slurry
 - Designed by slurry vendors for materials specific to IC industries
 - Oxide / Nitride
 - Polysilicon
 - Tungsten
 - Copper



CNF NanoCourses



CMP, page 10




CMP, page 5

CMP Processing issues

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- During planarization, removal rate is pattern dependant
- Damascene process has pattern issues as well
 - Erosion
 - Dishing
 - Pattern recess



CNF NanoCourses



CMP, page 11



CMP Defects

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Scratches
 - Big scratches caused by large agglomerated slurry clumps, loose diamond, and other large particles – should be preventable
 - Small ‘micro’ scratches caused by smaller slurry agglomerations – must develop process to be insensitive to microscratches
- Slurry particles on wafer
 - Important to adequately clean wafer after polishing
 - PVA brushes used in modern equipment
 - Dilute ammonium hydroxide used to get zeta potential ‘on your side’
 - Dilute HF can be used to etch particles off wafer



CNF NanoCourses



CMP, page 12



CMP Overview

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- CMP opens up new possibilities in nanofabrication
- Now being used in many other industries
 - Optoelectronics
 - MEMS
 - Hard disk drive heads
- Unique among etch techniques in that it is spatially selective
- Is not designed to do everything
- Adds its own challenges to a process flow



CNFS NanoCourses



CMP, page 13



NanoCourses 2004, Section 3

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Practical Thin Film Technology

The Flatland of Thin Films
Puttin' 'em on and Takin' 'em off

**Bonding, Embossing and
Soft Lithography Techniques**
by
Mandy Esch

Presented by the
CNF Technical Staff
for the education of CNF Users,
Potential Users, and Industrial Sponsors



CNF NanoCourses



Bonding & Embossing page 1



Bonding

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

**Bonding = Permanent or non-permanent
coupling of materials**

Methods:

- Anodic bonding
- Direct bonding
- Bonding with intermediate layers



CNF NanoCourses



Bonding & Embossing page 2



Bonding & Embossing, page 1

Anodic Bonding - Substrates

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses




Bonding & Embossing, page 3



Anodic Bonding

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Voltage: 500-1200 V
- Temperature: 350-500°C



CNF NanoCourses




Bonding & Embossing, page 4



Bonding & Embossing, page 2

Anodic Bonding

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



- Contain sodium ions
- Have a thermal expansion coefficient close to that of silicon



CNFS NanoCourses



Bonding & Embossing, page 5



Anodic Bonding

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Bio-MEMs
- microfluidics
- pressure sensors
- solar cells
- piezoresistive applications
- packaging

But: Because of the presence of charged mobile ions and the high voltages necessary, this technique can not be used for semiconductor devices.



CNFS NanoCourses




Bonding & Embossing, page 6



Silicon Fusion Bonding

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Bonding & Embossing, page 7




Silicon Fusion Bonding

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Pre-bonding



Annealing



Inspection with transmission infrared
microscopy, X-ray topography or ultrasonic
methods



CNF NanoCourses




Bonding & Embossing, page 8



Bonding & Embossing, page 4

Surface Properties

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



Si-O-Si bonds form due
to short range
intermolecular forces

Surface roughness
should be no
higher than 5 Å

Contamination or entrapped gases will
diminish the quality of the bond!

picture source: <http://www.sonoscan.com/systems/C-SAM%20AW-2000.htm>



CNF NanoCourses



Bonding & Embossing, page 9



Surface Preparation

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

RCA clean - SiOH groups

1) RCA1: NH₄OH (29%) : H₂O₂ (30%) : H₂O

1 : 1 : 5

for 5 min at 70°C

2) RCA2: HCl (37%) : H₂O₂ (30%) : H₂O

1 : 1 : 6

for 5 min at 70°C

3) RCA1

HF dip - SiH groups



CNF NanoCourses




Bonding & Embossing, page 10



Intermediate Layer Bonding

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Used to bond materials that cannot be bonded with anodic or direct bonding: for example gallium arsenide
- Non permanent bonding of a substrate to a handle wafer



CNF NanoCourses



Bonding & Embossing, page 11




Intermediate Layer Bonding

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Metals (eutectic bonding)
- Glass (glass-frit bonding)
- Glues
- PECVD oxide
- Photoresist
- PMMA
- Acrylic
- Waxes

To bond the wafers Force and Heat are necessary.



This type of bonding
can be non-permanent!



CNF NanoCourses





Bonding & Embossing, page 12



Hot Embossing

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Microstructuring of thermoplastic polymers (bulk material or thin film)
- High-precision molding of microfluidic components with a large aspect ratio and micro-optical components is possible



CNF NanoCourses




Bonding & Embossing, page 13




Hot Embossing

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

A) Microfluidics



B) Nano-Imprint Lithography



Several levels and back side alignment are possible.



CNF NanoCourses




Bonding & Embossing, page 14



Process

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

To avoid thermal stress between substrate and template, ΔT should be as small as possible.



CNRF NanoCourses



Bonding & Embossing, page 15



Materials for Embossing

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Substrates

- Thermoplastic bulk polymers such as polycarbonate, PETG, Acrylic
- Thin films such as PMMA, SU-8

- Molds

- Silicon processing
- CNC machining (limit 50 μm)
- LIGA (Ni)
- DEEMO



CNRF NanoCourses




Bonding & Embossing, page 16



Advantages

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Low-cost substrate material
- Easy way of microstructuring
- A complex micromachining step is only necessary once
- Rapid prototyping and production possible



CNF NanoCourses




Bonding & Embossing, page 17



Stamp Geometries

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- The stamp geometry defines the flow pattern the material undergoes.



CNF NanoCourses




Bonding & Embossing, page 18



Stamp Geometries

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Narrow grooves are easier to fill than big squares
- Angled sidewalls facilitate better de-embossing
- Antiadhesive layers such as fluorinated Teflon-like polymer films or self assembled monolayers of organic molecules improve phenomena observed during de-molding.



CNRF NanoCourses




Bonding & Embossing, page 19



Microfluidic Channels

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Kameoka et al., Anal. Chem., 73, p. 1935



CNRF NanoCourses



Bonding & Embossing, page 20



Example: Nano-Imprinting

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Stephen Chou et al., Science 272, p. 85





Fig. 4. SEM micrograph of a perspective view of strips formed by compression molding into a PMMA film. The strips, 70 nm wide and 200 nm tall, have a high aspect ratio, a surface roughness of <3 nm, and nearly perfect 90° corners.



CNFS NanoCourses



Bonding & Embossing, page 21



Soft Lithography

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Collective name for techniques based on self-assembly and molding
- Rapid inexpensive way of forming patterns
 - Micro-contact printing
 - Microfluidic printing
 - “Dip Pen”
 - Replica molding

For overview articles on soft lithography look for publications by G. M. Whitesides, Harvard University



CNFS NanoCourses




Bonding & Embossing, page 22



Microcontact Printing

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Bonding & Embossing, page 23




Microfluidic Printing

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Silicon
template

PDMS was
cured on the
silicon

PDMS placed
on a glass
slide



CNF NanoCourses



Bonding & Embossing, page 24




Bonding & Embossing, page 12

“Dip-Pen” Technology

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Piner et al., Science 283 (5402), 661



- 30 nm lines of alkanethiols



CNFS NanoCourses




Bonding & Embossing, page 25



Replica Molding

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- The elastomeric mold simplifies the separation between replica and mold



CNFS NanoCourses



Bonding & Embossing, page 26



Applications of Soft Lithography

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- **Biology and Biochemistry:**

- 1) Biochemical Assays
- 2) Capillary electrophoresis
- 3) Patterned Cell Culture

- **Patterning of Semiconductor Materials**

- 1) Patterning of non-planar (curved) surfaces
- 2) Transistor fabrication
- 3) Selective deposition (CVD) of thin films
- 4) Patterning with organic molecules (SAMs)



CNFS NanoCourses




Bonding & Embossing, page 27



Immobilization of Nucleic Acids

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Steel et al., Biophysical Journal, 79, 975-981



But: DNA will stick to gold surfaces ---
Block them with mercaptohexane!



CNFS NanoCourses



Bonding & Embossing, page 28



Pattern of Biomolecules

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Nucleic Acids
- Antibodies
- Organic Monolayers
- Enzymes
 - Covalent attachment
 - Adsorption
 - Encapsulation in gels
- **Functionality**
- **Accessibility**



CNRF NanoCourses



Bonding & Embossing, page 29



NanoCourses 2004, Part 3

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Practical Thin Film Technology

The Flatland of Thin Films
Puttin' 'em on and Takin' 'em off

Wet Etch Processes by Phil Infante

Presented by the
CNF Technical Staff
for the education of CNF Users,
Potential Users, and Industrial Sponsors



CNF NanoCourses



Wet Etch Processes, page 1



Wet Processes

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Many of the etching processes for thin film removal and pattern transfer involve liquid chemicals
- 20-25 years ago, etching processes for microelectronics were almost exclusively performed by wet chemistry
- The need for high resolution pattern transfer spurred the development of "dry etching" processes
- Today, plasma based etching is the norm in the micro-electronics industry
- However wet etching is still an integral part of micro-fabrication as it provides certain advantages over plasma processes



CNF NanoCourses



Wet Etch Processes, page 2



Wet Etch, page 1

Disadvantages

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- The major disadvantage of wet etching is poor resolution
- Wet etch processes are typically "isotropic," i.e., the lateral etch rate is the same as the vertical etch rate
- For "large" features this may be acceptable



CNF NanoCourses




Wet Etch Processes, page 3




Wet Etching

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Before etch:



After etch:



CNF NanoCourses



Wet Etch Processes, page 4




Wet Etch, page 2

Linewidth

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- However, if the linewidth is on the order of the film thickness, problems can occur



CNF NanoCourses



Wet Etch Processes, page 5



Advantages of Wet Etching:

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- 1) Inexpensive:
 - Chemicals cost on the order of \$8 per gallon
 - An etch sink and HEPA costs \$20,000
 - Plasma type etchers cost on the order of 0.1 to 0.3 million dollars and have higher operating costs
- 2) Batch processing results in high throughput
- 3) Etch rates are determined by chemistry alone
 - Etch rates for films are thus constant, provided the phase variables (temperature and concentration) are controlled
 - This results in very uniform etching (with proper agitation)
- 4) Because etch rates depend on chemistry alone, very high selectivities are possible
 - This is perhaps the most attractive feature of wet etching
 - 6:1 buffered HF etches SiO_2 at 110 nm/min
 - Silicon is not etched
 - Phosphoric acid at 160°C etches Si_3N_4 at 10 nm/min
 - SiO_2 etches at < 5 Å/minute



CNF NanoCourses




Wet Etch Processes, page 6



Wet Etch, page 3

Release Application

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Wet Etch Processes, page 7



Etching of Silicon with Potassium Hydroxide

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- KOH etches the <100> and <110> crystal planes faster than the <111> planes with a high degree of selectivity
- Generally the selectivity of <100> : <110> : <111> is about 300:600:1
- The KOH silicon etch has a high selectivity to SiO₂ and a near infinite selectivity to LPCVD Si₃N₄
- Typical KOH concentrations are around 30-40 % by weight
 - This gives 100 etch rates at about 1-2 μm/min
- Lowering the concentration gives slightly better etch rates but with decreased selectivity
 - Higher concentrations give the best selectivity between plane orientations



CNF NanoCourses




Wet Etch Processes, page 8



Wet Etch, page 4

Silicon Crystal Lattice

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNRF NanoCourses




Wet Etch Processes, page 9



<100> Si Wafer

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNRF NanoCourses




Wet Etch Processes, page 10



Wet Etch, page 5

<100> Si Wafer, Continued

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNRF NanoCourses




Wet Etch Processes, page 11



<100> Si Wafer, Continued

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNRF NanoCourses




Wet Etch Processes, page 12



Wet Etch, page 6

<110> Si Wafer

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNRF NanoCourses




Wet Etch Processes, page 13



<110> Si Wafer, Continued

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNRF NanoCourses



Wet Etch Processes, page 14



Wet Etch, page 7

Common Chemical Concentrations

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

Acids		wt%
Acetic acid	CH ₃ CO ₂ H	99.7 (minimum)
Hydrochloric acid	HCl	36.5-38.0
Nitric acid	HNO ₃	69.0-71.0
Perchloric acid	HClO ₄	69.0-72.0
Phosphoric acid	H ₃ PO ₄	85.0 (minimum)
Sulfuric acid	H ₂ SO ₄	95.0-98.0
Alkalies		wt%
Ammonium hydroxide	NH ₄ OH	28.0-30.0 (as NH ₃)
Hydrazine monohydrate	NH ₂ NH ₂ H ₂ O	99.0 (minimum)
Potassium hydroxide	KOH	85.0 (minimum)
Sodium hydroxide	NaOH	90.0 (minimum)
Other Chemicals		wt%
Ammonium fluoride sol.	NH ₄ F	40-41
Hydrogen peroxide sol.	H ₂ O ₂	30.0-32.0
Methanol	CH ₃ OH	99.8
2-Propanol	(CH ₃) ₂ CHOH	99.5 (typical)
Sodium peroxide	Na ₂ O ₂	96.0 (minimum)
Mixtures*		Vol
Aqua regia	HNO ₃ -HCl	1:3
Buffered HF (BHF)	HF-NH ₄ F	1:x (typically 1:6)
P-etch	HNO ₃ -HF-H ₂ O	1:3:60

* All mixtures in this chapter are by volume unless stated otherwise.



CNF NanoCourses



Wet Etch Processes, page 15



Common Wet Etch Processes

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

• Silicon Dioxide:

- **6:1 ammonium fluoride: 48% hydrofluoric acid**
 - Common name 6:1 Buffered Oxide Etch
 - Note: 48% HF is commonly called "Straight HF"
- **Etch rate -110 nm/min for thermal SiO₂:** Faster for CVD oxide
- **Selectivity to silicon:** Infinite
- **Selectivity to Si₃N₄:** 100:1
- **Does not lift photoresist:** If oxide stripping is to be done, i.e. no resist pattern, use straight HF and deionized water
- **10:1 HF:H₂O etches thermal oxide at 36 nm/min**

Note: All etch rates at 25°C except where noted

ALL RATES ARE APPROXIMATE!!



CNF NanoCourses



Wet Etch Processes, page 16



Wet Etch, page 8

Wet Etch Processes, Continued

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- **Aluminum:**

- 4: Phosphoric acid
- 4: Glacial acetic acid
- 1: Nitric acid
- 1: Deionized water
- Etch Rate: 40 nm/min
- Selectivity to Si and SiO₂: Infinite

- **Polysilicon:**

- 150: Nitric acid
- 75: Deionized water
- 1: 48 % HF
- Etch Rate: 200 nm / min
- Selectivity to SiO₂: 10:1
- Note: Evolves heat when mixed



CNF NanoCourses



Wet Etch Processes, page 17



Wet Etch Processes, Continued

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- **Silicon Nitride.**

- Phosphoric Acid @ 160°C
- Etch rate: 10 nm/min
- Selectivity to SiO₂ and Si: > 20:1

- **SEE:**

- Ghandi, "Microfabrication" or Vossen and Kern, "Thin Film Processes" for extensive tables of wet etch solutions and properties



CNF NanoCourses



Wet Etch Processes, page 18



Wet Etch, page 9

Safety

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- The strong acids and bases pose a serious contact hazard
 - Proper handling and protective gear are essential
 - Nitrile rubber gloves and a face shield are mandatory
 - A vinyl apron is recommended



CNF NanoCourses



Wet Etch Processes, page 19



Disposal

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Wet chemical waste must be disposed of properly
 - Cornell does not perform “in house” neutralization
 - Waste bottles for each chemical mixture should be created
 - Do not have “common” Acid or Base waste containers



CNF NanoCourses



Wet Etch Processes, page 20



Wet Etch, page 10

High Temperature Processing



CNRF NanoCourses



Wet Etch Processes, page 21



Outline

- Annealing
- Thermal Oxidation of Silicon
- Thermally Activated Chemical Vapor Deposition (CVD)
- Plasma-Enhanced Chemical Vapor Deposition (PECVD)



CNRF NanoCourses



Wet Etch Processes, page 22



Wet Etch, page 11

Annealing

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Heat sample between 400 and 1200°C
- Expose sample to inert or reducing ambient



CNF NanoCourses



Wet Etch Processes, page 23




Reasons for Annealing


CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Changes microstructure of substrates or films
- Changes conductivity, stress, etch resistance, etc
- Can cause two materials to react

Metal
Poly



Metal silicide
Poly



CNF NanoCourses



Wet Etch Processes, page 24



Wet Etch, page 12

Thermal Oxidation of Silicon

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Heat Si to high temperature $> 700^{\circ}\text{C}$
- Expose Si to oxidizing ambient O_2 or H_2O
- Si reacts with oxidant to form SiO_2



CNF NanoCourses




Wet Etch Processes, page 25



Mechanism

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Oxidant diffuses through oxide to Si-SiO₂ interface to react with Si



CNF NanoCourses



Wet Etch Processes, page 26




Wet Etch, page 13

Growth of Oxide

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- From the densities and molecular weights of silicon and silicon dioxide we can calculate that:
 - For a growth of oxide of thickness = d , a layer of silicon = 0.44 d is consumed
- The oxide grows *down as well as up!*
 - (This can sometimes be quite a problem)



CNF NanoCourses



Wet Etch Processes, page 27



Oxidation Rates

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Two rate limiting processes:
 - *Chemical reaction* at oxide-Si interface
 - *Diffusion* of oxidant through the oxide layer on the surface to the oxide-Si interface
- The slower of these two processes determines the oxidation rate



CNF NanoCourses



Wet Etch Processes, page 28



Chemical Reaction Limited Oxidation

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Rate is determined by chemical kinetics
- Characterized by a linear rate constant
 - Oxide thickness = $C_1 \times$ (oxidation time)
- Linear rate relationship holds for oxidation on bare silicon or silicon with a thin surface oxide



CNF NanoCourses



Wet Etch Processes, page 29



Diffusion Limited Oxidation

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Rate is controlled by oxidant diffusion through existing oxide
- Characterized by parabolic rate constant
 - $(\text{oxidation time}) \times C_2 = (\text{oxide thickness})^2$
- Parabolic rate relationship holds for oxidation on silicon with a *substantial* thickness of surface oxide



CNF NanoCourses



Wet Etch Processes, page 30



Factors Affecting Oxidation Rates for Thin Oxides

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Surface orientation
 - Atomic density
 - Number of available Si bonds
 - Steric hinderance (bond stress)
- --> Orientation of surface affects surface kinetics and hence *linear rate constant*
- Impurities in silicon
 - Affect linear rate constant



CNF NanoCourses



Wet Etch Processes, page 31



Factors Affecting Oxidation Rates for Thick Oxides

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Oxidizing ambient
- Oxidant pressure
 - Diffusion of oxidant proportional to partial pressure of oxidant
- Impurities in oxide
 - Affect parabolic rate constant



CNF NanoCourses





Wet Etch Processes, page 32



Pressure and Orientation

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses




Wet Etch Processes, page 33



Boron Doping

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

THERMAL OXIDATION OF SINGLE CRYSTAL SILICON



CNF NanoCourses




Wet Etch Processes, page 34



Wet Etch, page 17

Boron Doping

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNRF NanoCourses




Wet Etch Processes, page 35



Typical Oxidation System

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNRF NanoCourses



Wet Etch Processes, page 36



Wet Etch, page 18

Dry Oxidation

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Oxidize in O₂
- Anneal in N₂ or Ar to stabilize charges at oxide-Si interface
- Oxidation rate is slow - better process control for thin oxides
- PRACTICAL THICKNESS RANGE:
 - 80 Å to 1500 Å



CNF NanoCourses



Wet Etch Processes, page 37



Wet Oxidation

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Oxidant is a mixture of H₂ and O₂ (steam)
- Fast oxidation rate (large A, B/A)
- PRACTICAL THICKNESS RANGE:
 - 500 Å to 1.2 μm
- Requires special gas injector



CNF NanoCourses



Wet Etch Processes, page 38



Wet Etch, page 19

Thermal Oxide Characteristics

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Excellent insulator
 - Picoamp leakage current
- 10 Megavolt/cm dielectric strength
 - (1000 Å oxide breaks down at 100 V)
- Thermal SiO₂ is non-contaminating to most other materials used in microfabrication



CNF NanoCourses



Wet Etch Processes, page 39



Types of Cleaning Processes

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Pre-oxidation clean:
 - Since oxidation temperatures are high, contaminants will diffuse into the MOS structure
 - Concentrations of some contaminants as low as 3E10 atoms/cm² can cause shifts in electrical characteristics and impair reliability
 - A cleaning process is required to remove organic and metallic contaminants prior to oxidation
- Two popular cleans:
 - 1)RCA clean
 - NH₄OH+H₂O₂+H₂O
 - HCl+H₂O₂+H₂O
 - 1) H₂SO₄+ H₂O₂ (liquid piranha)



CNF NanoCourses



Wet Etch Processes, page 40



Wet Etch, page 20

Furnace Chlorine Sources

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Remove alkalis and metals from furnace chambers
- HCl Gas
 - The classic Cl source
 - Can corrode plumbing, adding more contamination than it removes
- 1,1,1 trichloroethane (TCA)
 - Liquid source
 - Bubble a carrier gas (nitrogen) through liquid
 - Reacts inside tube to form HCl and CO₂
 - Chance of corrosion greatly reduced



CNF NanoCourses



Wet Etch Processes, page 41



Oxidation Capabilities at CNF

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Wet and dry thermal oxidation
- TCA or HCl chlorine source
- 100 Å to 1.2 µm thickness
- Restrictions:
 - Whole 3-6 inch wafers preferred
 - Must be device quality silicon
 - No metallizations prior to oxidation
 - Polymers must be removed *prior* to pre-furnace clean
 - Implanted areas must be capped with oxide



Process history must be reviewed by MOS Manager

CNF NanoCourses



Wet Etch Processes, page 42



Chemical Vapor Deposition (CVD)



CNF NanoCourses



Wet Etch Processes, page 43



Chemical Vapor Deposition

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Substrates are placed in a reactive ambient at a temperature and pressure designed to induce a controlled deposition of a film on a substrate

Common CVD Reactions:

PR	REACTANTS	METHOD	TEMP (°C)	COMMENTS
Polysilicon	SiH ₄	LPCVD	580-650	May be <i>in situ</i> doped
Silicon Nitride	SiH ₄ + NH ₃	LPCVD	700-900	
	SiCl ₂ H ₂ + NH ₃	LPCVD	650-750	
	SiH ₄ + NH ₃	PECVD	200-350	
	SiH ₄ + N ₂	PECVD	200-350	
SiO ₂	SiH ₄ + O ₂	APCVD	300-500	Poor step coverage
	SiH ₄ + O ₂	PECVD	200-350	Good step coverage
	SiH ₄ + N ₂ O	PECVD	200-350	
	Si(OCH ₃) ₄ [TEOS]	LPCVD	650-750	Liquid source, conformal
	SiCl ₂ H ₂ + N ₂ O	LPCVD	850-900	Conformal
Doped SiO ₂	SiH ₄ + O ₂ + PH ₃	APCVD	300-500	PSG
	SiH ₄ + O ₂ + PH ₃	PECVD	300-500	PSG
	SiH ₄ + O ₂ + PH ₃ + B ₂ H ₆	APCVD	300-500	BPSG, low temperature flow
	SiH ₄ + O ₂ + PH ₃ + B ₂ H ₆	PECVD	300-500	BPSG, low temperature flow



CNF NanoCourses




Wet Etch Processes, page 44



Wet Etch, page 22

Basic Mechanisms of CVD

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



- 1) Transport of reactant to surface
- 2) Adsorption of reactant at surface
- 3) Reaction at surface
- 4) Desorption of product from surface
- 5) Transport of product away from surface

- Energy to drive the reaction can be supplied by a variety of sources (thermal, electrons, photons)
- The SLOWEST event will determine the deposition rate



CNF NanoCourses



Wet Etch Processes, page 45



Reactions

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- In reality, chemical reactions may not only take place at the surface but in the gas phase as well
- Heterogeneous Reactions
 - Occur at or near the substrate surface
 - Are much more desirable
 - Generally produce higher quality films
- Homogeneous Reactions
 - Reactions occur in the gas phase
 - Generate clusters of depositing material
 - Result in poor adhering and low density films
 - Produce films with higher defects
- Heterogeneous reactions are favored over homogeneous reactions



CNF NanoCourses



Wet Etch Processes, page 46



Transport of Reactants to the Surface

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Mean Free Path

$$\lambda = kT/\sqrt{2\pi P\sigma^2}$$

- P = Pressure
- σ = Diameter of molecule
- k = Boltzman constant

- Diffusion to Surface

- Boundary Layer:
 - A gas velocity transition region between the solid surface of the sample or chamber ($v = 0$) and the free gas stream ($v = x$)

$$\delta = 2L/3\sqrt{Re}$$

- d = Boundary layer
- L = Length of region
- Re = Reynolds number



CNF NanoCourses



Wet Etch Processes, page 47



Reynolds Number

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Reynolds number:

- A dimensionless number used to represent the ratio inertial effects to viscous effects in fluid motion

$$Re = \rho v L / \mu$$

- v = gas velocity
- μ = viscosity
- ρ = fluid density
- L = Length from edge

- Reynolds number is proportional to gas velocity and the boundary layer is inversely proportional to $Re^{1/2}$

- Faster gas velocity = smaller boundary layer



CNF NanoCourses




Wet Etch Processes, page 48



Reynolds Number, Continued

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



CNF NanoCourses



Wet Etch Processes, page 49



Transport of Reactants

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Transport of Reactants to the Surface Depends on:
 - Reactant concentration in the gas stream
 - Deposition temperature
 - Pressure
 - Boundary layer thickness
- We want to optimize process parameters to get the gas to the surface to react rather than react in the gas stream



CNF NanoCourses



Wet Etch Processes, page 50



Wet Etch, page 25

Adsorption

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Depends on substrate binding energy
- Depends on reactant vapor pressure
 - Vapor pressure $\sim \exp [Temp]$
- Non-zero probability that a reactant will leave surface before it can react
- Depends on gas species used for deposition



CNF NanoCourses



Wet Etch Processes, page 51



Surface Reaction

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Surface reactions can be modeled by a thermally activated process:
$$R = R_0 \exp [E_a/kT]$$
- The surface reaction increases with increasing temperature
- At high temperatures, the reaction rate will proceed faster than the gases can reach the sample
 - This is a *mass transport limited* process
- At low temperatures, the reaction rate is slower than the gas supply rate
 - This is a *reaction rate limited* process



CNF NanoCourses




Wet Etch Processes, page 51



Growth Rate for CVD Films

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY



- Reaction rate limited processes require precise temperature control and are more tolerant to gas transport fluctuations
- Mass transport limited processes require precise control of reactant concentration at the surface and less control over the process temperature



CNF NanoCourses



Wet Etch Processes, page 53



Step Coverage

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

• Mass transport limited case:


- The thickness at any point is dependent on the supply of reactants to the site
- Reactant surface diffusion path length (L_s) is a strong function of temperature and mean free path length (λ) is a f_n of pressure



$\lambda, L_s \gg$ step geometry



$\lambda \gg$ step, $L_s \ll$ step



$\lambda, L_s \ll$ step



CNF NanoCourses



Wet Etch Processes, page 54



Reaction Limited Case:

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Lower temperature pushed process to be reaction rate limited without adversely effecting gas transport
- Transport of reactants to surface is efficient -- good conformality/uniformity
- Some gas chemistries may be transport limited even at lower temperatures



CNF NanoCourses



Wet Etch Processes, page 55



Types of CVD Processes

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Atmospheric CVD (APCVD)
- Low pressure CVD (LPCVD)
- Plasma-enhanced CVD (PECVD)



CNF NanoCourses



Wet Etch Processes, page 56




Wet Etch, page 28

APCVD

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Typical reactor:

- Pressure = 760 torr



CNF NanoCourses



Wet Etch Processes, page 57



APCVD, Continued

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Film Uniformity

- Reaction constant is on the order of mass transfer coefficient
 - Transport effects are significant
 - Fair to poor uniformity

- Step Coverage

- Mean free path on the order of step height
 - Poor transport over features
 - Poor step coverage



CNF NanoCourses



Wet Etch Processes, page 58




LPCVD

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Typical reactor:

- Pressure range 0.1 to 3 torr



CNF NanoCourses



Wet Etch Processes, page 59



LPCVD, Continued

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Film Uniformity

- Deposition rate is reaction limited
 - Mass transfer is a strong inverse function of pressure
 - Chemical reaction constant is a weak function of pressure
 - Efficient transport and surface reaction limited means good uniformity

- Step Coverage

- Mean free path large compared to step geometry
 - Good step coverage



CNF NanoCourses



Wet Etch Processes, page 60



Wet Etch, page 30

Problems with LPCVD

- Small gas volume results in gas depletion or loading effect
- Process optimization can be difficult, especially for production volumes
- Film deposits on chamber walls, can cause particulate problems



CNF NanoCourses



Wet Etch Processes, page 61




PECVD

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Typical reactor:

- Pressure range
0.1 torr to 0.6 torr
- Temperature range
100°C to 400°C



CNF NanoCourses



Wet Etch Processes, page 62



Wet Etch, page 31

Advantages & Disadvantages

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Advantages:

- RF plasma excites reaction
- Temperature can be very low
- Can deposit films on structures that cannot see high temperatures
 - Metals, GaAs, polyimide...
- Energetic radicals tend to have high sticking coefficients and migrate well along surfaces after adsorption
- Good uniformity/conformality
- Higher deposition rates than LPCVD

- Disadvantages:

- Films are not stoichiometric
- By-products incorporated into the films
- Gas phase reactions generate particulates



CNF NanoCourses



Wet Etch Processes, page 63



CVD Processes at CNF

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- LPCVD Silicon Nitride

- 800°C
- SiH₂Cl₂+ NH₃

- LPCVD SiO₂

- 420°C
- SiH₄+ O₂

- LPCVD Silicon Oxynitride

- 850°C
- SiH₂Cl₂+ NH₃+ N₂O or O₂

- LPCVD SiO₂

- 850°C
- SiH₂Cl₂+ N₂O

- LPCVD Polysilicon

- 620-650°C
- SiH₄ +optional PH₃ or B₂H₆



CNF NanoCourses



Wet Etch Processes, page 64



Wet Etch, page 32

PECVD 25-400°C

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- Silicon Nitride



- Silicon Oxide



- a-silicon



- a-carbon



- SiC



CNF NanoCourses



Wet Etch Processes, page 65



CVD Safety

CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY • CORNELL NANOSCALE FACILITY

- The major hazard of CVD applications is the gases used:

Properties of Common Gases used in CVD	
GAS	PROPERTIES
Silane	Toxic, flammable, pyrophoric
Dichlorosilane	Toxic, flammable, corrosive
Phosphine	Very toxic, flammable
Diborane	Very toxic, flammable
Arsine	Very toxic, flammable
Hydrogen chloride	Toxic, corrosive
Ammonia	Toxic, corrosive
Hydrogen	Nontoxic, flammable
Oxygen	Nontoxic, supports combustion
Nitrous Oxide	Nontoxic, nonflammable
Nitrogen	Usually inert
Argon	Inert



CNF NanoCourses



Wet Etch Processes, page 66



Wet Etch, page 33